Panasonic

持込修理

パナソニック音響製品保証書

本書はお買い上げの日から下記期間中故障が発生した 場合には本書裏面記載内容で無料修理を行なうことを お約束するものです。詳細は裏面をご参照ください。

品	番		SJ-MI	R250	
保証期間		お買い上げE	***** 本亿	1 年間	1
お買い	上げ日		年	月	日
£	ご住	所			
客様	お名	前			様
你	電	話 ()	-	
	住所	・氏名			
販					
売					
店					
	電	話 ()	-	

松下電器産業株式会社 AVC ネットワーク事業グループ

〒 571-8505 大阪府門真市松生町 1 番 4 号 TEL (06) 6909-102

ご販売店さまへ 印欄は必ず記入してお渡しください。



Panasonic®

ポータブル MD レコーダー Portable MD Recorder 取扱説明書 Operating Instructions

品番 SJ-MR250

お買い上げいただき、まことにありがとうございました。 ご使用に際して、必ず本機(SJ-MR250)とBeatJamのユーザー登録をお願いいたします。(詳しくは56ページをご覧ください。)

この取扱説明書と保証書をよくお読みのうえ、正しくお使いください。そのあと 保存し、必要なときにお読みください。



保証書付き



NetMD

この取扱説明書の印刷には、植物性大豆油インキを使用しています。

PRINTED WITH

この取扱説明書はエコマーク認

便利メモ (おぼえのため、記入されると便利です。) 定の再生紙を使用しています。

上手に使って上手に節電

販売店名	i	()	-	お買い	上げ日	年	月	日
お 客 様ご相談窓口	i	()	-	品	番	SJ-	MR2	50

松下電器産業株式会社 AVC ネットワーク事業グループ

〒571-8505 大阪府門真市松生町1番4号

Matsushita Electric Industrial Co., Ltd. AVC Network Business Group 1-4 Matsuo-cho, Kadoma City, Osaka, Japan 571-8505

もくじ

_ , _	
	安全上のご注意 ・・・・・・・・・・・・・・4
	付属品の確認・・・・・・・・・・・・・・9
	各部のなまえ・・・・・・・・・・・・・10
34= /H	電源の準備・・・・・・・・・・・・・・13
準備	充電式電池で使う・・・・・・・・・・・・13
	乾電池(別売り)で使う・・・・・・・・・15
しよう	電池残量表示について・・・・・・・・・・15
	スピーカーの接続 ・・・・・・・・・・16
	HOLD (ホールド) 機能・・・・・・・・16
	MDの入れかた・出しかた・・・・・・・17
	録音する機器と接続する ・・・・・・・18
	CDなどを録音する ・・・・・・・20
	シンクロ録音 ・・・・・・・・・・・・・・22
録音	録音に関するお知らせ・・・・・・・・・・・・24
多小口	マイクで録音する ・・・・・・・・・・・25
してみよう	録音に便利な機能・・・・・・・・・・・26
	トラックマークのつけかた ・・・・・・・・・26
	録音残り時間を確かめる ・・・・・・・・・・26
	録音感度を調節する ・・・・・・・・・・・・27
	MD を聞く・・・・・・・・・28
	スピーカーで聞く ・・・・・・・・30
	いろいろな聞きかた・・・・・・・・・31
	曲を前後にとび越す(スキップ機能)・・・・・・・31
	早送り・早戻し(サーチ機能)・・・・・・・・31
	好みの曲から聞く(トラック指定機能)・・・・・・31
番件	好みの曲を登録順に聞く(イントロスキャンメモリー再生)32
再生	音質を変える ・・・・・・・・・・・・・・34
してみよう	グループモードで聞く・・・・・・・・・・35
O Cora J	くり返し聞く(リピートプレイ)/順不同に聞く(ランダムプレイ) 36
	その他の便利な機能・・・・・・・・・37
	コントラストの調整 ・・・・・・・・・・・37
	リモコン表示パネルの点灯 ・・・・・・・・・37
	リモコンの操作受付音・・・・・・・・・・・37
	表示内容を切り換える・・・・・・・・・・38
	カナ、漢字で登録された曲名の表示 ・・・・・・・39

	1 曲を 2 曲に分ける (ディバイド)・・・・・・・・4 曲を移動する (ム - ブ)・・・・・・・・・・・・4 全曲を消す (オール イレース)・・・・・・・・・・・・4
編集 てみよう	1曲ずつ消す(トラック イレース)・・・・・・・・4 2 曲を 1 曲にまとめる(コンバイン)・・・・・・・4 曲をグループにまとめる(グループ)・・・・・・・4 MD にタイトルをつける・・・・・・・・・・5 曲やディスクにタイトルをつける・・・・・・・・5 文字入力のしかた・・・・・・・・・・・・・・・5 他の MD にタイトルをコピーする(タイトルステーション)・5

MDを編集する・・・・

Net MD で使う

	パソコンに戻す(チェックイン)・・・・・・・・62
ì	他の機器と組み合わせて使う・・・・・・64
	ステレオ機器と接続する ・・・・・・・・・・・64
	別売り品の紹介・・・・・・・・・・・・65
	使用上のお願い・・・・・・・・・・・・65
	MD について・・・・・・・・66
	MD の種類 ・・・・・・・・・・・・・・・・6 6
	取扱上のお願い・・・・・・・・・・・・・66
	MDの用語解説 ・・・・・・・・・・・・・・66
	MDの録音・編集について ・・・・・・・・・・67
	著作権について・・・・・・・・・・・・68

MDのシステム上の制約・・・・・・・・69故障かな!?・・・・・・・・70Q&A(よくあるご質問)・・・・・・・73こんな表示が出たら・・・・・・・74保証とアフターサービス・・・・・・・76Operating Instructions・・・・・・80

パソコンと組み合わせて使う・・・・・・55 こんなことができます・・・・・・55

MD に録音する(チェックアウト)・・・・・・・61

ご参考に

ω
ñ
ĬĞ.
õ
≃
×
O.
∝

安全上のご注意

お使いになる人や他の人への危害、財産への損害を未然に防止する ため、必ずお守りいただくことを、次のように説明しています。

表示内容を無視して誤った使い方をしたときに生じる危害や損害 の程度を、次の表示で区分し、説明しています。



この表示の欄は、「死亡または重傷などを負 う危険が切迫して生じることが想定される」 内容です。



この表示の欄は、「死亡または重傷などを負 う可能性が想定される」内容です。



この表示の欄は、「傷害を負う可能性または 物的損害のみが発生する可能性が想定され る」内容です。

お守りいただく内容の種類を、次の絵表示で区分し、説明してい ます。(下記は、絵表示の一例です。)



このような絵表示は、してはいけない「禁止」 内容です。



この絵表示は、必ず実行していただく「強制」 内容です。

マルチクレードルについて



⚠ 注意

内部に異物を入れたり、使用中にふとんや布でおおったりしない 故障の原因や、熱がこもって火災や感電の原因にな ることがあります。

付属以外のスピーカーを接続したり、接続端子に触れたりし ない



ショートや発熱により、火災や感電の原因になるこ とがあります。

本機について

分解・改造しない



機器が故障したり、金属物が入ると、やけどや火災 の原因になります。

点検や修理は、販売店へご依頼ください。

分解禁止

自動車やバイク、自転車などの運転中は使用しない



周囲の音が聞こえにくく、交通事故の原因 になります。 歩行中(特に、踏切や横断歩道)でも周囲の交通に 十分注意してください。

異常に温度が高くなるところに置かない



機器表面や部品が劣化するほか、火災の原因になるこ とがあります。

夏の閉め切った自動車内や、直射日光の当たるとこ ろ、ストーブの近くでは特にご注意ください。

ステレオインサイドホン使用時は音量を上げすぎない



耳を刺激するような大きな音量で長時間続けて聞く と、聴力に悪い影響を与えることがあります。

車外の音が聞こえないような音量で聞きながら運転 すると、交通事故の原因になることがあります。

ステレオインサイドホンなど肌に直接触れる部分に異常を感 じたら使用を中止する



そのまま使用すると炎症やかぶれなどの原因になる ことがあります。

ふとんや布でおおった状態で使用しない



熱がこもって、ケースが変形したり、火災や感電の 原因になることがあります。

♠ 警告

プラグは根元まで確実に差し込む



差し込みが不完全ですと、感電や発熱による火災の原 因になります。

傷んだプラグ・ゆるんだコンセントは使用しないで ください。

ぬれた手で、ACアダプターの抜き差しはしない



ぬれた手でマルチクレードルやコンセントから AC アダプターの抜き差しをすると、感電の原因になり ます。

ぬれ手禁止

コード・プラグを破損するようなことはしない



傷つけたり、加工したり、熱器具に近づけたり、無理 に曲げたり、ねじったり、引っ張ったり、重い物を載 せたり、束ねたりしない。

傷んだまま使用すると、感電・ショート・火災の原 因になります。

コードやプラグの修理は、販売店にご相談ください。

コンセントや配線器具の定格を超える使い方や、交流 100 V 以外での使用はしない



たこ足配線等で、定格を超えると、発熱による火災 の原因になります。

AC アダプターについて(つづき)

プラグのほこり等は定期的にとる



プラグにほこり等がたまると、湿気等で絶縁不良と なり火災の原因になります。AC アダプターを抜き、 乾いた布でふいてください。

長期間使用しないときは、ACアダプターを抜いてください。

抜き差しは AC アダプター本体を持つ



コードを引っ張ると、コードが傷ついたり、ちぎれ たりし、火災や感電の原因になることがあります。

付属の AC アダプターを使う



指定外の電圧や電源で使用すると、火災や感電の原 因になることがあります。

充電式電池について

専用のマルチクレードルと AC アダプターを使って充電する



指定外の機器で充電すると、電池の液もれや、発熱、 破裂の原因になります。

充電式電池も必ず指定のものをご使用ください。

はんだ付け、分解、改造したり、火の中へ投入、加熱はしない 電池の液もれや、発熱、破裂の原因になります。

充電式電池について(つづき)



① 警告

⊕と⊝をショートさせない



電池の液もれや、発熱、破裂の原因になります。 ネックレスなどの金属物といっしょに携帯、保管す る場合は、必ず付属の充電式電池ケースに入れてく ださい。

電池には安全のためにビニールのチューブをかぶせ ています。これをはがすとショートの原因になりま すので、絶対にはがさないでください。はがれたも のは使わないでください。

乾電池について

注意

電池は正しく取り扱う



⊕と⊝は正しく入れる 長期間使用しないときは、取り出しておく

電池は誤った使い方をしない

充電しない



加熱、分解したり、水、火の中へ入れたりしない ネックレスなどの金属物といっしょにしない (乾電池入りの乾電池ケースも同様です。) 被覆のはがれた電池は使わない

取り扱いを誤ると、電池の液もれにより、火災や周囲汚損の原 因になります。

万一液もれが起こったら、販売店にご相談ください。 液が身体についたときは、水でよく洗い流してください。

付属品の確認



お使いになる前に、まず付属品を確かめてください。

AC アダプター (RFEA413J-2S)

マルチクレードル

(RFE0102)

スピーカー

(RFA2069)

ステレオインサイドホン (L0BAB0000162)




ジョイント式リモコン (N2QCBD000024)



ニッケル水素充電式電池 充電式電池ケース(RFA0475-Q) から取り出してご使用ください。



乾電池ケース (RFA1537-S2)



USB ケーブル (K2KZ4CB00003)



Net MD 用ソフトウェア CD-ROM ユーザー登録ハガキ BeatJam 取扱説明書

付属品の買い替えについて


サービスルートでお買い求めいただけます。上記かっこ内の品番でお買い 上げの販売店にご注文ください。(ニッケル水素充電式電池は別売り品 HHF-1PSC/1B または HHF-AZ01S/1B をお買い求めください。)


別売り品でお買い求めいただけるもの


「別売り品の紹介」(➡ 65ページ)をご参照ください。

各部のなまえ

⑰ などの数字は、参照ページです。










10

むなどの数字は、参照ページです。








電源の準備

充電式電池で使う


充電する

1 充電式電池を本体に入れる

お買い上げ時も充電必要




2 本体をマルチクレードルに取り付ける




3 AC アダプターをマルチクレードルに接続する

[DC IN 4.5 V ◆ • ◆ •] 端子



充電開始!



表示 (" CHARGE ") が消えたら充電 完了 (フル充電) です。付属の充電式 電池では約 3 時間 30 分かかります。


お願い

必ず付属のACアダプターをご使用ください。付属以外のACアダプターをご使用になると故障の原因になることがあります。



電源の準備(つづき)

充電式電池で使う(つづき)



AC アダプターを接続していても、 本体に充電式電池を入れずにマルチ クレードルに取り付けると [NO BATTERY] と表示され、電源が入 りません。

雷池の持続時間

「主な仕様」(➡97ページ)をご覧ください。 充電可能回数は

約300回です。(充電しても持続時 間が極端に短い場合は、寿命です。)

充電式電池の買い替えは ニッケル水素充電式電池 HHF-1PSC/1B HHF-AZ01S/1B

長期間使用しないときは 節電のため本体の電源を切り、ACア ダプターをコンセントから抜いておく ことを、おすすめします。

[/OPR OFF]を押して電源を切った 状態でも、ACアダプターが約 1.6 Wの電力を消費しています。

お願い

マルチクレードルに本体を取り付け てお使いになるとき、傾けたり、乱 暴に置いたりして衝撃を与えないよ うにしてください。

本体をマルチクレードルに取り 付けて使うときは

録音や編集、スピーカーで聞くとき、 Net MDを使用する場合など

充電式電池を入れた本体をマルチクレ ードルに取り付け、ACアダプターを 接続する(🖦 13ページ)

充電式電池を本体に入れることに より、録音中や Net MD で曲を転 送している途中に、誤って[▲, EJECT]を押し、本体がマルチク レードルから外れても、音楽デー タが記録されなかったり、壊れた りすることを防ぐことができます。

(お知らせ)

充電時は、必ず付属の、または左記 「充電式電池の買い替えは」の別売 り充電式電池をお使いください。電 池残量を使い切らなくても継ぎ足し 充電が可能です。

電源を切った状態でのみ、充電でき ます。

Net MD使用中は充電できません。 " CHARGE "表示が出ないときは、 一度 AC アダプターをマルチクレー ドルの [DC IN 4.5 V ◆ ● ◆ 1 端子 から抜き、再び差し込んでください。 充電中、AC アダプターと充電式電 池は熱を持ちますが、異常ではあり ません。

長期間使用しなかった後は、充電し ても通常の持続時間より短くなるこ とがあります。充電、放電をくり返 すと、通常に戻ります。

使用後は、貴重な資源を守るためにリサイクルへ!

使用済み電池の届け先:

お買い上げの販売店、または最寄りの松下電器の販売店・ サービスセンター・販売会社へ

もしくは、(社)電池工業会へご確認ください。

(ホームページ: http://www.baj.or.jp)



2 本体に取り付ける

本体底面

ニッケル水素電池使用

乾電池(別売り)で使う

1 乾電池を入れる

パナソニックアルカリ乾電池を おすすめします。



(付属)単3形アルカリ乾電池(別売り)

乾電池と充電式電池を併用すると より長時間ご使用いただけます。(電池持続時間については ➡97ページ)

電池残量表示について

4段階で表示されます。

電池残量表示が点滅したら しばらくすると電源が切れます。充電 式電池は充電し、乾電池は新しいもの に交換してください。

(お知らせ)

本体を取り付けたマルチクレードル に、ACアダプターを接続したり、本 体に電池を入れたときに、動作音が聞 こえることがありますが異常ではあり ません。



お願い


録音する場合は、本体に充電式電池 を入れてマルチクレードルに取り付 け、ACアダプターを接続してお使 いになることをおすすめします。 乾電池を使用して録音する場合は、

必ず本体に充電式電池を入れて併用 してください。

マルチクレードルとスピーカーを接続する

スピーカーにはL(左) R(右)の区別がありません。左側に置いたスピーカ ーを L 端子に、右側に置いたスピーカーを R 端子に接続してください。

使いかたについては ➡ 30 ページ



お願い

必ず AC アダプターをマルチ クレードルに接続して、充電 式電池を入れた本体を取り付 けてください。(充電式電池だ けではスピーカーから音が出 ません。)

付属のスピーカー以外は接続 しないでください。また付属 のスピーカーを別の機器に接 続して使わないでください。 スピーカーに磁気の影響を受 けやすいもの (キャッシュカ ードや定期券)を近づけない

でください。

HOLD (ホールド)機能


誤って操作ボタンが押されても受け付 けないようにする機能です。使用して いないときに電源が入ったり、使用中 に再生、録音などの操作が中断するこ とを防ぎます。

本体とリモコンにそれぞれ HOLD つまみがあり、別々に機能します。

ホールド状態で操作ボタンを押すと 数秒間 "HOLD "と表示します。


(電源切時は、[▶/▮▮]、 [REC/LP MODE →]を操作したときのみ表示。) リモコン

動作中、つまみの位置を[HOLD]にす ると数秒間 "HOLD"と表示します。



MD の入れかた・出しかた

①[OPEN]つまみを矢印の方向に スライドさせる ふたが開きます。




②ディスクのラベル面をふた側に して,中央部を押して、ロックす ス




ディスクを取り出すには [OPEN]つまみを矢印の方向に

ふたが開いてディスクが出てきます。

スライドさせる



ディスクの情報を



約1分後自動的に電源が切れます

たときは、"BLANK DISC"と表示 されます。


録音する機器と接続する

本機に接続する機器の種類によって、使用する接続コードや接続端子が異なりますので、下表でお確かめのうえ、正しく接続してください。

接続する機器と接続端子

接続コード

本機の接続端子



本機の[OPT/LINE IN]端子はデジタル・アナログの兼用です。 接続コードの種類によって、自動的にデジタル入力またはアナログ入力に切り換わります。

アナログ接続で録音する場合、誤って本機のヘッドホン端子[介]に接続しないよう 特に注意してください。誤って接続すると本機が故障するおそれがあります。



パソコンの音楽データを本機で録音する方法については、55~63ページをご 覧ください。

適切な音量で録音するには

接続する機器によって、本機の録音感度を調節してください。(➡ 27 ページ) アナログ接続で再生側の機器のヘッドホン端子に接続した場合、接続した機器の 音量を適切に調節してください。

18



準備

[OPT/LINE IN]

録音する機器と接続する(➡ 18~19ページ)



ヘッドホン端子 に接続しないで

光デジタルケーブル

接続は、本機が停止中に行ってください。

デジタル接続 光出力端子 アナログ接続

ヘッドホン / ラ イン出力端子

アナログ接続する場合[MIC(PLUG IN POWER)]端子には何も接続しないでください。C


REC/LP MODE →

矢印の方向にスライドさせて

録音待機状態にする

接続する機器によって、録音感度を調節すること ができます。(➡ 27 ページ)

高音質録音(➡ 20ページ)



さらに矢印の方向にスライドさせて

通常ステレオ/LP2/LP4 モードを選ぶ スライドするたびに以下のように切り換わります。

LP2 # LP4 # 通常ステレオ(表示なし)

MD**LP** (LP2/LP4)モードでの録音時間 LP2: 2倍長時間ステレオ録音(80分ディスクで最大160分録音可能)

LP4: 4 倍長時間ステレオ録音(80分ディスクで最大320分録音可能)



押す

夕 接続した機器を再生する 録音済みの MD を入れると、前の録音部分の続きか ら録音されます。



一時停止するには

曲番が1つ増えます。

録音を再開するには もう一度押す。

1 分間停止状態のまま にすると、自動的に電

"UTOC Writing"が表示され、 源が切れます。

NTAC Writing

高音質録音について

通常ステレオ録音の場合、デジタル、アナログ、マイ ク、いずれの入力方式でも高音質録音になります。 (LP2/LP4 モードではできません。)

電源はなるべくACアダプターをお使いください。

このとき、必ず本体に充電式電池を入れてください。 録音中に [▲, EJECT]を押さないでください。

録音中は振動を与えないでください。特に録音終了

時の "UTOC Writing"表示中は注意してください。

録音、録音待機中はふたが開きません。無理に開け

CD などを録音する

充電式電池を

■/OPR OFF ►/II

マルチクレードル

本体を取り付けて、ACアダプター

をつないでください。(➡13ページ)

録音を正しく行うために

正しく録音できない場合があります。

ようとすると、故障の原因になります。

入れる

録音待機状態にすると本体の表示パネルに"HDES" (High Density Encoding System)と表示されます。


停止するには 停止状態

> UTOC を記録します。(**→** 66 ページ)

電源を切るには 電源切状態

CD などを録音する (つづき) (

ホールド状態を解除する。 本体に充電式電池を入れる。



シンクロ録音

シンクロ録音

録音もとの機器の入力音を検知して、自動的に録音を開始したり、一時 停止します。

1曲シンクロ録音(連続 CD1 曲目ねらい取り機能)[デジタル接続のみ] CDの1曲目のみをシンクロ録音します。1曲目の録音が終わると、録 音待機状態になります。CDを交換し、再び1曲目を再生すると、録音 が自動的に始まります。

録音する機器と接続する(➡ 18~19ページ)



矢印の方向にスライドさせて

録音待機状態にする

さらにスライドするとLP2/LP4 モードが選べます(→ 21 ページ)



押して

録音モードを選ぶ

押すと次のように切り換わります。




デジタル接続

アナログ接続

シンクロ録音 1曲シンクロ録音 通常録音 SYNC # SYNC1 # 表示なし シンクロ録音 诵常録音 SYNC < 表示なし

音声信号が常に出ているソースの場合、自動的に録音が始まるのでご 注意ください。

録音モードを "SYNC"に設定すると CS/BS 放送、FM 放送など、



(お知らせ)

次のような場合、1曲シンクロ録音はできません。

- CD を 2 曲目以降から再生したとき
- ② 2 枚組の CD などで、1 曲目の曲番が " 1 " と表示されない CD を録音しよ うとしたとき

シンクロ録音、1曲シンクロ録音中は、手動で操作して一時停止することはで きません。

マイクから録音するときはシンクロ録音できません。

お願い

シンクロ録音時、曲によっては頭の部分が切れて録音される場合があります。こ のようなときは、20~21ページ(通常録音)の手順で録音してください。

録音に関するお知らせ

トラックマークのつきかた

以下のときに自動的にトラックマークがつきます。

デジタル接続

CD や MD から録音する場合 CD や MD の曲番どおりに、トラック マークが曲の変わり目につきます。 (ただし、CDやMDによっては、曲 番どおりにつかないこともあります。) CD や MD 以外のデジタルソースから 録音する場合

2 秒以上の無音部分を曲の変わり目と してトラックマークがつきます。

手動でつけるには

(➡ 26ページ)

アナログ接続

2 秒以上の無音部分を曲の変わり目と してトラックマークがつきます。

手動でつけるには

(➡ 26ページ)

お知らせ

曲間が短い、曲間に雑音が多いなどの 理由で、トラックマークがつかない場 合があります。また無音や音の小さい 部分があると、曲中でもつく場合があ ります。このようなときは、録音終了 後に、編集機能を使ってトラックマー クを修正してください。(➡ 40~ 45ページ)

接続する機器について(デジタル接続の場合)

ポータブルCDプレーヤーから録音するときは、ACアダプターを使用し、耐 振機能を "OFF" にしてください。(詳しくはお手持ちのポータブルCDプレ ーヤーの説明書をご覧ください。)

本機はサンプリングレートコンバーター内蔵のため、CS/BS チューナーや DAT デッキなどサンプリング周波数の異なるデジタル機器に接続しても、自 動的に本機の周波数に変換して、デジタル録音できます。

MDLP(長時間ステレオ)録音について

1 枚の MD に通常ステレオ録音、LP2 ステレオ録音、LP4 ステレオ録音を混 ぜて行うことができます。


LP2/LP4 ステレオ録音された曲は、曲名の頭に自動的に「LP:」という文字 が付き、MD**LP** 再生に対応していない機器で再生すると曲名の頭に「LP:」 と表示されます。本機で再生した場合は表示されません。

LP4 ステレオ録音は、特殊な圧縮方式によって長時間録音を実現しているた め、録音されるものによっては、ごくまれに瞬間的な雑音が入る恐れがありま す。音質を重視する場合は、通常ステレオ録音またはLP2ステレオ録音をお すすめします。

電池を入れ替えたり、ACアダプターを抜き差しすると、録音モードは通常ス テレオ録音に戻ります。

マイクで録音する

ホールド状態を解除する。 本体に充電式電池を入れる。 録音用 MD を入れる。



マイクを接続する(本機が停止中に行ってください。)

[OPT/LINE IN]端子には何も接続しないでください。

本機の動作音が録音されないように、マイクを本機から遠ざけてください。 ステレオインサイドホンを使っていてハウリング (ピーという音) が起きたら、 インサイドホンとマイクの距離を離すか、音量を下げてください。

矢印の方向にスライドさせて REC/LP MODE → 録音待機状態にする

さらにスライドするとLP2/LP4 モードが選べます (➡ 21ページ) **イ**



① [▶/**II**]を押す


2 マイクに向かって音を出す

録音中に 曲番が1つ増えます。 一時停止するには 録音を再開するには もう一度押す。 1 分間停止状態のまま 録音中に 停止するには ※ロ・・・ ■/OPR OFF ►/III を押す にすると、自動的に電 源が切れます。 停止中に 電源を切るには を押す 電源切状態

トラックマークのつけかた 手動で、または一定時間の間隔を設定すると、その間隔で自動的につきます。(■ 26 ページ) と お使いいただけるマイク


ステレオマイク(別売り: RP-VC200、RP-VC300)をお買い求めください。

録音に便利な機能




トラックマークのつけかた

録音部分に「区切り」をつけることにより頭出しに便利です。(➡ 66ページ)




マイクから録音するとき、"AUTO"は 選べません。

手動でつけるには




録音残り時間を確かめる



録音モードが LP2,LP4 の場合はそれ ぞれのモードに対応した残り時間が表示されます。

録音感度を調節する




設定をしない場合、アナログ、マイク 接続では " REC SENS H " に、デジ タル接続では " REC SENS L " にな ります。

録音状況に合った感度の設定

"REC SENS H"に適した録音 アナログ接続でポータブル機器から録音 デジタル接続で CS チューナー等か ら録音

マイク接続で会議等を録音

" REC SENS L"に適した録音 アナログ接続でシステム機器から録音 デジタル接続で通常の録音 マイク接続でライブ等の大音量を録 音 録音レベルを手動で調節するには



録音中に設定を変えることはできません。


アナログ、マイク接続で設定が REC SENS H, Lのとき、録音レベ ルは自動的に調節されます。またお 好みに合わせて手動で調節すること もできます。

デジタル接続の場合、録音感度の設 定を変えてもインサイドホンから聞 こえる音の大きさは変化しません。

お願い

一旦録音を終えると設定は解除されます。次に録音待機状態にしたとき、必要に応じて設定し直してください。

MD を聞く



MDLP ステレオ再生

LP2/LP4 ステレオ録音された曲を再生することがで きます。(表示パネルに "LP-2" あるいは "LP-4" が 表示されます。)

モノラル再生

モノラル録音モードで録音されたディスクを再生する ことができます。(表示はされません。)

ディスク再生時に、録音された方法によって通常ステレオ、 LP2、LP4、モノラル再生が自動的に切り換わります。

リジューム機能について


停止後、または電源が切れたあと、本体の[▶/▮▮]、また はリモコンの[▶/■]を押すと、停止したところから再生 します。ただし、ディスクを取り替えたり、電池を入れ 直した場合は、1曲目から再生します。

お知らせ)

再生中に、リモコンの表示が消えたり、表示内容に異 常が見られたときは、いったんリモコンのプラグを本 体から抜き、もう一度しっかりと差し込んでください。 本機は振動に対して、音飛びしにくくなっていますが、 連続した振動に対しては、音が途切れる場合があります。

準備

- ① ホールド状態を解除する。(➡ 16ページ)
- ② MD を入れる。(**⇒** 17ページ)



本体

プラグタイプ ステレオミニ(M3)

リモコン



押して

再生を始める

全曲の再生を終了すると自動 的に停止します。



VOI 💷 (小さく) (大きく)



本体

押して

音量を調節する

音量レベルは0~25まで



(小さく) (押し続けると連続的に切り換わります。)

一時停止するには

再牛中に

を押す

リモコンでは一時停止は できません。

リモコン



再生を再開するには もう一度押す。

停止するには

停止状態

再生中に

再生中に





1分間停止状態のままにすると、自動的に電源が切れます。


電源を切るには

電源切状態

停止中に

停止後、約1分すると自 動的に電源が切れます。

スピーカーで聞く



- 1 本体に、充電式電池を入れる (➡ 13ページ)
- 2 本体をマルチクレードルに取 リ付ける (➡ 13ページ)
- 3 AC アダプターをマルチクレ ードルに接続する (➡ 13ページ)

必ず AC アダプターを接続して ください。充電式電池だけでは スピーカーから音が出ません。

4 スピーカーをマルチクレード ルに接続する(➡16ページ)

30 リモコンで行ってください。

音量の調節は


+ → , VOL/CURSOR1 で調節で きます。(本体の[VOL,-,+]でも 調節できます。)

お知らせ

録音中の音をスピーカーで聞く ことができます。(ただし、マイ クから録音する場合は聞けませ h.)

パソコン上の音楽データの演奏 を、本機のスピーカーで聞くこ とはできません。

いろいろな聞きかた



曲を前後にとび越す (スキップ機能)



くり返し押すと、連続して曲をと び越せます。

早送り・早戻し <u>(サ</u>ーチ機能)



好みの曲から聞く (トラック指定機能)



押して、選んだ曲を再生する




選んだ曲からディスクの最終曲ま で順に再生します。

「 |◀◀] または 「 ▶▶]] を押したまま にすると、曲が連続して変わります。

L١

ろな

₹




好きな曲を登録する

好みの曲を登録順に聞く(イントロスキャンメモリー再生) リモコン操作のみ

曲のイントロを聞きながら、好きな 順 番 に 登 録 で き ま す。 (最大 16 曲まで)

停止中に数回押して"INTRO"を表示させる



操作をしない場合、約1分後に自動的に電源が切れます。

押す



1 曲目から順に始めの約 10 秒間 のみイントロスキャン再生します。 イントロスキャン中もスキップ 機能は使えます。 登録したい曲番が点滅中(約 10秒間)に押す



この操作をくり返して、曲番を登録する。

再生が始まってから押してください。 最終曲までいくと、最初の曲に 戻ります。1度登録した曲は、 とばして再生します。

押す



登録が完了します。 もう一度押すと、メモリー再生が 始まります。

好きな曲を登録する(つづき)

"END"、"FULL"が表示されたらこれ以上の登録はできません。表示(約2秒間)後、登録は自動的に終了します。

END:ディスクのすべての曲が登録されました。

FULL:登録曲数が最大の16曲 になりました。これ以上 登録できません。

登録し直したいときは 全曲取消

停止中、" MEMO " と表示されて いる状態で [T.MARK/EQ] を約 5 秒間押す。

"CLEAR"と表示され、登録内容 は消えます。その後、"INTRO" 表示になるので登録し直してくだ さい。(■ 32ページ)

イントロスキャンを解除するには 停止中に[PLAY MODE]を押す。 ("INTRO"の表示が消えると通常 の再生に戻っています。)


お知らせ)

グループモード (➡ 35ページ) ではイントロスキャン再生、メモリー再生(右記)はできません。

再生する(メモリー再生)

" MEMO " が表示されている場合はこの手順をとばし次に進む

停止中に数回押して"MEMO"を表示させる



押す ピッ 曲番 MEMO ®

登録順に再生が始まります。 メモリー再生中、リモコンでは 曲名の表示後、" MEMO " と表 示されます。

[▶/■]を押すと、停止します。

メモリー再生を解除するには (登録内容は消えません。) 再生中あるいは停止中に[PLAY MODE]を押す。

(" MEMO " の表示が消えると 通常の再生に戻っています。)

登録した曲が解除されるのは


全曲取消 の操作をしたとき

電池が切れたとき ふたを開けたとき 電池ぶたを開けたとき 録音待機状態にしたとき [EDIT]を押し編集操作をしたとき Net MDを確立したとき

0.10

3 CT 655

いろいろな聞きかた(つづき)




音質を変える



スピーカーで聞くときは 充電式電池を入れた本体をマルチクレードルに取り付けて、ACアダプターを接続すると、以下のように切り換わります。

押すたびに




リモコンも同様の表示で切り換わります。


イントロスキャン中、メモリー再生 停止中(➡ 32 ~ 33 ページ)は、 音質を変えることができません。

グループモードで聞く

グループ設定 (ディスク内の連続した複数の曲をいくつかのグループにまとめる) されたディスクでは、グループ単位で再生が楽しめます。

まず、グループ設定をしてください。 (➡ 46 ~ 47ページ)







曲番は選んだグループの 1 曲目が "1"と表示されます。

停止中でも、リモコンに"INTRO" または"MEMO"が表示されてい たら(イントロスキャンメモリー再 生➡ 32 ~ 33ページ)グループモ ードにできません。

グループの設定がされていないディスクの場合"NO GROUP"(リモコンでは"NO GRP")と表示されます。

グループ内で曲をスキップする には

再生中に[◄◀]、[▶▶|]を押す

グループ内で曲をサーチするには 再生中に[$|\blacktriangleleft\blacktriangleleft|$]、 $[\blacktriangleright \blacktriangleright]$]を長押しする

グループ内で好みの曲から聞くには 1. 停止中に[I◀◀]、[▶▶]を押し て曲を選ぶ

2. [►/**II**] (本体)または[►**/I**] (リモコン)を押す

選んだ曲からグループの最終曲まで順に再生します。

POTRASA

リモコン操作時に約5秒間点灯し、

表示パネルを約5秒間点灯させるこ とができます。

リモコンの操作受付音

リモコンの操作ボタンを押したときに 間 鳴る操作受付音を消すことができます。

進備

- ①電源を入れて、本体をホールド状 態にする。(➡ 16 ページ)
- ②本体の[▶/ ▮▮]を押しながら


BeepOFF (



BeepON

コントラストの調整

本体とリモコンの表示パネルを、 それぞれコントラスト調整するこ とができます。





きます。

本体: 0(うすい)~29(こい) リモコン: 0(うすい)~15(こい) - : うすく +: こく

CONTRAST 15

リモコンでは "CONT15" のよう に表示されます。

MODE •LIGHT/ - DISP PLAY MODE VOI (=II II+) ■/OPR OFF ►/II HOLD → COLO

いろいろな聞きかた(つづき)

くり返し聞く(リピートプレイ)/順不同に聞く(ランダムプレイ)






全曲リピートでは、再生中でもディス ク(グループ)の1曲目と最終曲をは さんでの曲のとび越し、早送り、早戻 しができます。


ランダムプレイ中は、再生し終わった 曲へのとび越し、早戻しはできません。 ディスクを取り替えたとき、グループモ ードの切り換え(➡ 35ページ)を行った ときは、もう一度設定し直してください。

その他の便利な機能(つづき)



表示内容を切り換える

リモコン操作のみ



グループ名の前には"*"、ディスク名の前には"』"が表示されます。 曲名、グループ名、ディスク名が入っていないディスクの場合、本体では"NO TITLE"リモコンでは "ー」・・・"が表示されます。


⇒押すたびに切り換わります⇒数秒表示した後、自動的に切り換わります

スクロール後、"G 1" が消えて、*以下の 文字が表示されます。


お知らせ

ディスクモード (GROUP OFF)のときと グループモード (GROUP ON)のときで、


表示が異なります。(*** 35ページ)







表示内容を切り換える(つづき)



グループ内曲番 丙 再生経過時間

Symphony

曲名

カナ, 漢字で登録された曲名の表示

MD には文字を登録できる異なる 2 つの領域があります。

半角文字領域


カタカナ、アルファベット、数字、 記号入力可能

全角文字領域

漢字、ひらがな、カタカナ、アルファベット、数字、記号入力可能

全角、半角両方の領域にタイトル入力されている場合、どちらの領域で入力された文字を表示するか、選ぶことができます。

本機では半角文字領域で入力された文字も全角で表示されます。




本機では 漢字、ひらがななど(全角 文字領域)の入力はできません。付属 のアプリケーションソフト BeatJam を使って入力してください。

半角、全角それぞれ一方の領域にの み文字が入力されている場合は、上 記の設定に関わらず入力されている 領域の文字が表示されます。


2QT6558


2.0

本体だけでは編集できません。必ずマルチクレードルに取り付けて操作し てください。

















曲を2曲に分ける(ディバイド)

EDIT

分けたい曲の 再生中に押す

押して VOL/CURSOR "DIVIDE?" を選ぶ



ENTER <u>DIV POS+00</u>0?-

押した位置からの約4秒間が(モノ ラル、LP2 では約8 秒間、LP4 で は16秒間)くり返し演奏されます。

分けた位置がずれていたら 押して位置を調整する

- 128 ~ VOL/CURSOR ~ + 127 (約8秒) (十一) (十一 (約8秒)

前後8秒で調整できます。(モノラ ル、LP2では16秒、LP4では 32秒)





"UTOC Writing "点灯後、編集 が完了し停止状態になります。


編集を途中で止めるには [EDIT]を押す

お知らせ)

タイトルがついている曲を分ける と、後ろの曲はタイトルなしとなり ます。

ディバイド機能は、停止中に行うこ とはできません。

MD を編集する(つづき)



曲を移動する(ム-ブ)

(例:2曲目を3曲目に移動する。)

停止中に押す





移動する曲番を選ぶ表示画面になります。

USB ON/OFF



途中で編集を止めるには [EDIT]を押す

" UTOC Writing " 点灯後、編集 が完了し停止状態になります。

曲を移動する(ム・ブ)(つづき)

再生(一時停止)中でもできます

- 1 移動したい曲の再生(一時停止) 中に[EDIT]を押す
- 2 [-- +- VOL/CURSOR] を押して、"MOVE?"を選び、 [ENTER, USB ON/OFF]を押す
- 3 [-- -, + -- , VOL/CURSOR] を押して、移動先の曲番を選び [ENTER, USB ON/OFF]を押す 確認の表示が出ます。
- 4 [ENTER, USB ON/OFF]を押す "UTOC Writing"点灯後、編集 が完了し停止状態になります。

全曲を消す(オール イレース)

停止中に押す EDIT

押して " ALL VOL/CURSOR (+-) ERASE?"を 選ぶ





"UTOC Writing"点灯後、編集が 完了し停止状態になります。

("BLANK DISC "が表示されます。)

途中で編集を止めるには [EDIT]を押す

(お知らせ)

オール イレース機能は、再生(一時 停止)中に行うことはできません。

D を編集する つづき

1曲ずつ消す(トラック イレース)

停止中に押す

VOL/CURSOR 押して"TRACK ERASE?"を 選ぶ

押す

ENTER
USB ON/OFF

TRK ERASE -1 ?
曲番を選ぶ表示画面になります。

押して消したい曲を選ぶ 曲番 vol./cursor 曲番 下がる 上がる





途中で編集を止めるには [EDIT]を押す

再生(一時停止)中でもできます

- 1 消したい曲の再生(一時停止) 中に[EDIT]を押す

確認の表示が出ます。

3 [ENTER, USB ON/OFF]を押す"UTOC Writing"点灯後、編集が完了し停止状態になります。

2曲を1曲にまとめる(コンバイン)

(例:2曲目と3曲目をまとめる。)

EDIT

まとめる 2 曲 の後ろの曲の 再生中に押す

VOL/CURSOR 押して (+--) (+---) " COMBINE ? " を選ぶ



確認の表示が出ます。

上記の場合、曲番 2 の終端 8 秒間 と、曲番 3 の曲頭 8 秒間が、くり 返し演奏されます。(モノラル、 LP2 では 1 6 秒、LP4 では 3 2 秒)



途中で編集を止めるには [EDIT]を押す

停止中でもできます

- 1 停止中に[EDIT]を押す
- 2 [━ -,+ → , VOL/CURSOR] を押して、" COMBINE? " を 選び[ENTER, USB ON/OFF] を押す

まとめる2曲を選ぶ表示画面になります。

確認の表示が出ます。

4 [ENTER, USB ON/OFF]を押す M D m UTOC Writing "点灯後、編集 を が完了し停止状態になります。 編

(お知らせ)

曲名は前の曲のものになります。 コンバインの操作ができない原因と して、次のようなものがあります。 1 曲目の再生中に、コンバイン の操作を行ったとき

まとめようとする2曲が通常ステレオ録音、モノラル、LP2、 LP4それぞれ異なる録音モードで録音されているとき を編集する(つづき)

QT6558

曲をグループにまとめる(グループ)

グループをつくる(GROUP SET)

連続した何曲かをグループにまとめて タイトルをつけることができます。 グループは最大 99 個まで作れます。

(例:3~5曲目をグループにまとめる。)

停止中に押す

volcursor 押して GROUP?" を選ぶ

押す

ENTER
USB ON/OFF

GRP
SET 7-

押す

USB ON/OFF

グループにまとめる最初の曲を選ぶ表示画面になります。






グループにまとめる最後の曲を選 ぶ表示画面になります。





文字を入力する (➡ 52 ページ)



途中で編集を止めるには [EDIT]を押す

お知らせ)

1 曲だけでもグループにすることができます。

例)5曲目だけでグループ2をつ くる。



グループを追加する場合、曲の並びの順にグループ番号が付きかわります。

例)上図の1曲目と2曲目をグルー プにすると、グループ1、2が それぞれグループ2、3になる。



グループにまとめられない例 連続していない曲どうしをグルー プにまとめることはできません。



1 曲を複数のグループに入れる ことはできません。




POTESS

D

本機でグループ編集を行った MD を、グループ機能に対応していない 機種で編集操作を行うとグループの 管理情報が使えなくなる可能性があ ります。

本機でグループ編集を行った MD を、グループ管理機能に対応してい ない機種で再生するとディスクタイ トルが下記のように正しく表示され ません。

例) 0; MY BEST//1-3;CLASSIC//4-8...



曲をグループにまとめる (グループ)(つづき)

グループタイトルを変更する (GROUP TITLE)

(例:グループ3のタイトルを変更する。)

停止中に押す EDIT

押して VOL/CURSOR $(+ \rightarrow)$ "GROUP?" を選ぶ

押す ((ENTER) GRP -ŠEŤ?-USB ON/OFF


押して "GRP TITLE ? "を選ぶ GRP -TÌTLE?-(--) (+-)

押す ENTER -Ġĺ*CLASS USB ON/OFF タイトルを変更するグループを選 ぶ表示画面になります。


押してタイトルを変えたいグル ープを選ぶ VOL/CURSOR -ĠģĸJAZZ (+ <u>-</u>



文字を入力する (➡ 52ページ)



途中で編集を止めるには [EDIT]を押す










MD にタイトルをつける




曲やディスクにタイトルをつける

ディスク名は最大 100 文字、曲名は 1 曲につき最大 100 文字 (MD**LP** 長 時間録音されたものでは最大 97 文字) まで入力できます。

1 枚の MD には最大 1792 文字まで入力できます。ただし、 MD**LP** 長時間録音をしたり、グループの設定をすると入力できる文字数は減ります。 (➡ 51 ページ) 全角文字領域には入力できません。 (➡ 39 ページ) BeatJam を使って入力してください。


ディスクタイトルをつける







文字を入力する (➡ 52 ページ)



ディスクタイトルを入力したあとは

自動的に曲のタイトルをつける表示 画面になります。「トラックタイト ルをつける」(➡ 51ページ)の曲番 を選ぶ手順から操作してください。

タイトル入力を途中で止めるには [EDIT]を押す

トラックタイトルをつける

EDIT

停止中に押す

"TITLE?" が表示されます。







文字を入力する (➡ 52 ページ)



"UTOC Writing"点灯後、編集が 完了します。その後、再び曲番を 選ぶ表示画面になり、続けてタイ トルを入力することができます。

タイトル入力を途中で止めるには [EDIT]を押す

再生(一時停止)中でもできます

- タイトルをつけたい曲の再生 (一時停止)中に[EDIT]を押す
- 2 [ENTER, USB ON/OFF]を押す 文字入力画面になります。
- 3 文字を入力する (➡52ページ)
- 4 [ENTER, USB ON/OFF]を押す "UTOC Writing"点灯後、編集 が完了し停止状態になります。

(お知らせ)

再生中に曲のタイトルをつけたと き、編集が終わるまで、その曲はく り返し演奏されます。

タイトル人力できる文字数 100文字を超えるタイトルがつい ているディスクのタイトルを、本機 で変更すると、"TITLE OVER"が 表示され、文字入力画面に入ります。 ただし[ENTER, USB ON/OFF]を 押し、編集を完了した時点で100


文字を超える文字は削除されます。

MD**LP** 長時間録音された曲にはトラックタイトルに「LP:」3 文字分が自動的に記録されるため、曲数が多いと入力できる文字数は減ります。またグループの設定をすると、グループの管理情報が記録されるため、同様に入力できる文字数は減ります。カナ文字で入力する場合はその約半分の文字数になります。

- 例)50 曲を MD**LP** 長時間録音 し、 4 グループ設定した場合
- ★ 1 タイトル平均 英数字では約 25 文字、カナ文字で は約 11 文字入力できます。

RQT6558

MD にタイトルをつける(つづき)



文字入力のしかた

タイトル入力画面にしたあと、以下の方法で入力してください。







右に移り、次の入力状態になります。

文字の種類と各ボタンに割り当 てられた文字

各ボタンを押すたびに、1文字ずつ順 に表示されます。

ボタン	カタカナ	アルフェ	アベット	数字
	G	大文字	小文字	1
17	アイウエオ アイウエオ			1
(2 Å)	カキクケコ	ABC	abc	2
(3 that DEF	サシスセソ	DEF	def	3
(4 %)	タチツテト ッ	GHI	ghi	4
(5 ±	ナニヌネノ	JKL	jkl	5
(6 MNO)	ハヒフへホ	MNO	mno	6
7 PT QRS	マミムメモ	PQRS	pqrs	7
(8 TUV)	ヤユヨ ャュョ	TUV	tuv	8
9 W 72	ラリルレロ	WXYZ	wxyz	9
0735	ワヲン゛゜			0
SPACE	! " # \$ % & / : ; <	'() * - = > ? @		

お知らせ

数字入力時、または文字入力時に異なるボタンを押すと、前に入力した数字・文字が確定されます。

押してカーソルを動かし、削除 する文字の上に置く

VOL/CURSOR +

左に移動

右に移動

(DELETE) 押す

カーソル位置の文字が削除され、 後ろに文字があるときは前に詰ま ります。

文字の間に新しい文字や空白を入れるには

押してカーソルを動かし、挿入 位置の右の文字の上に置く

VOL/CURSOR

左に移動

右に移動

新しい文字を入れるとき (プ) など入力したい文字・数字・記号ボタンを押す

空白を入れるとき

SPACE 押す

。 を入力するには

押す

濁点(゛)や半濁点(゜)は表記可能なカタカナの後ろにだけ入力できます。あり得ない表記の場合は選択候補として現れません。

文字を変更するには

- 1 変更したい文字を削除する
- 2 新しい文字を入力する

入力中に 1 文字空けるには

[+ → , VOL/CURSOR]を押す カーソルが 1 つ右に移動します。

途中で編集を止めるには [EDIT]を押す

(お知らせ)

記号の"/"は連続して入力することはできません。

Net MD でできること

パソコン上に蓄積した音楽データを、BeatJam で OpenMG 形式 ²に変換し、 本機に転送して MD に録音できます。(➡ 61 ページ)

LP2/LP4 モードでも録音できます。(モノラル録音はできません。) また、各曲の タイトルも記録されます。


音楽 CD の場合はパソコンへの録音と同時に MD にチェックアウトすることができます。 録音した MD は、CD から録音した MD と同じように、本機や他の MD 機器で再生 することができます。またアナログ接続で他の MD に曲を録音することもできます。 1 つの音楽データをチェックアウトできる回数には、制限があります。(詳しくは BeatJamの取扱説明書や配信サイトの説明をご覧ください。)

チェックアウトした音楽データをパソコンに戻せば(チェックイン)、再び別 のメディアにチェックアウトして使用することができます。(● 62 ページ) パソコンから本機を操作して、MDの曲を並べ変えたり、タイトルを付けたり できます。(**■** 63ページ)

2 OpenMG 形式:著作権保護のために音楽データを暗号化した形式です。

音楽は、著作物として著作権法に保護されています。 本機および Beat Jam では、著作権保護技術「OpenMG」を使用しています。

MD にタイトルをつける(つづき)



他の MD にタイトルをコピーする(タイトルステーション)

MD につけたタイトルを一時的に本機に記憶させ、他の MD にコピーすることができます。 操作のまえに


再生専用 MD や、未録音の MD (BLANK DISC) は使用できません。

両方のMDの曲数が同じときだけ、コピーできます。

コピー先のMDにタイトルがついている場合、本機能を使うと、タイトルはすべて新 しいものに置き換わります。









途中で編集を止めるには [EDIT]を押す

お知らせ)

LP2/LP4 で録音された曲のタイトルを 通常ステレオ録音の曲にコピーすると タイトルの頭に「LP:」が表示されます。 コピー元のディスクがグループ編集されて いる場合グループの情報もコピーされます。

パソコンと組み合わせて使う

こんなことができます

ご使用の前に

パソコンに必要な環境については BeatJamの取扱説明書をご覧ください。

お知らせ

Beat Jam と Net MD USB ドライバーは Windows OS のパソコンにのみインストールできます。Macintosh OS のパソコンにはインストールできません。 SJ-MR250 と付属のアプリケーションソフト、ドライバーをインストールしたパソコンの組み合わせでのみ、Net MD が正しく動作します。 複数の SJ-MR250 を同時に接続したり、他の Net MD 機器を組み合わせたりしたときの動作は保証いたしません。

推奨環境を満たしていても、そのすべてのパソコンの動作を保証するものでは ありません。

本機からのパソコン操作はできません。

パソコンの音は本機のスピーカーまたはステレオインサイドホンからは聞こえません。

Macintosh は米国その他の国で登録された米国 Apple Computer, Inc.の商標です。

Microsoft および Windows は米国 Microsoft corporation の米国および その他の国における登録商標です。

「BeatJam」は株式会社ジャストシステムの登録商標です。

OpenMG、Net MD はソニー株式会社の商標です。

その他、システム名、製品名は、一般に各開発メーカーの登録商標あるい は商標です。なお、本文中では™、® マークは明記しておりません。

ユーザー登録のお願い

本機(SJ-MR250)と Beat Jam のご使用に際して、バージョンアップなどのサポートを受ける場合に必要ですので、必ずそれぞれのユーザー登録をしていただきますようお願いいたします。

本機(SJ-MR250)

インターネットを利用して、当社ホームページで登録していただくか (アドレス: http://www.panasonic.co.jp/products/audio/index.html)、 ハガキを使用して登録していただくことができます。詳しい登録方法については、同梱の「ユーザー登録について」ハガキをご覧ください。

BeatJam

インターネットを利用して登録するか、または付属のユーザー登録ハガキを使用して登録してください。(ハガキはCD-ROM といっしょに透明の袋の中に入っています。)



インストールする

初めて Net MD を使用する場合は

まずアプリケーションソフト BeatJam と Net MD USB ドライバーをパソコン にインストールする必要があります。

BeatJam と Net MD USB ドライバーは付属の CD-ROM に入っています。パソコンの指示に従ってインストールしてください。

BeatJam、パソコンの取扱説明書もあわせてご覧ください。

OS インストール用の CD-ROM が必要になる場合があります。お手元にご用意ください。

1 BeatJam と Net MD USB ドライバーのインストール

- **1** パソコンの電源を入れ、OS を 起動させる
- ② CD-ROM (付属)をパソコンの CD-ROM ドライブに入れる セットアップ開始画面が表示され ます。
- むットアップ開始画面の "BeatJamのセットアップ"をク リックする

あとは、画面の指示に従ってイン ストールしてください。

必要なアプリケーション、ドライバー が全てインストールされます。

セットアップ画面が表示されな いときは

BeatJam 取扱説明書の 12 ページ「CD-ROM を入れてもセットアップ 開始画面が表示されない」の操作を行ってください。

お知らせ

OS の設定によっては、下記のような 画面が表示されることがあります。 " 続行 " をクリックして、インストー ルを続けてください。



画面はWindows XP Home Editionの一例 (➡ 次ページに続く)

インストールする(つづき)

2 接続

USBケーブル(付属)を使って、本機とパソコンを接続するパソコンに付属の取扱説明書もあわせてご覧ください。

お願い

必ず付属の USB ケーブルで接続してください。

USB ハブおよび USB 延長ケーブ ル経由で接続した場合の動作は保証 しません。

USBポートがパソコンに複数ある場合は、ルートハブ対応の端子に接続してください。(ルートハブ対応の端子についてはパソコンに付属の取扱説明書をご覧ください。)

パソコンや本機の電源が入っている 状態で USB ケーブルを抜き差しす るときは

パソコン側を抜き差ししてください。 抜いた後にもう一度差し込むときは、 5秒以上の間隔を開けてください。す ぐに差し込むと正しく動作しないこと があります。

パソコン(市販) USB 端子へ ₽⊕ USB ケーブル (付属) .ooo (CEED) 50000 5000 ÚSB 端子へ 00 3 マルチクレードル後面 ACアダプターを 接続する。 充電式電池を本体 に入れる。

3 確認

BeatJam と Net MD USB ドライバーが正しくインストールされたかを確認してください。 BeatJam

正しくインストールされると、パソコンのデスクトップ上に Beat Jam、JS ユーザー登録・確認、 Beat Stream のアイコンが現れます。

Net MD USB ドライバー

- マルチクレードルの USB ONOFF を押して Net MD を確立する
 本体の表示パネルに"Net MD"が表示されます。
- ② デバイスが認識されているか確認する (➡ 59~60ページ) 画面のリスト内にある項目は、ご使用のパソコン環境に応じて異なる場合 があります。

Windows 2000 Professional をご使用の場合

- ① "スタート"メニューから"設定" "コントロールパネル"を選びク リックする
- ②コントロールパネルの画面で、 "システム"のアイコンをダブルク リックする
- ③ " ハードウェア " のタブを選び、"デバイスマネージャ"をクリックする"表示"が"デバイス(種類別)"になっているか確認してください。
- ④デバイスが認識されていることを 確認する
 - "USB (Universal Serial Bus) コントローラ"の項目の中に"Net MD"が認識されていることを確認してください。



Windows XP Home Edition/Professional をご使用の場合

- ① " スタート " メニューから " コント ロールパネル " を選びクリックする
- ②コントロールパネルの画面で、 "パフォーマンスとメンテナンス" のアイコンをクリックする
- ③ " システム " のアイコンをクリック する
- ④ " ハードウェア " のタブを選び、" デバイスマネージャ " をクリック する
 - "表示"が"デバイス(種類別)"に なっているか確認してください。
- ⑤デバイスが認識されていることを 確認する

"USB (Universal Serial Bus) コントローラ"の項目の中に"Net MD"が認識されていることを確認し てください。

画面の一例



T6558

インストールする(つづき)

Windows 98/98 Second Edition または Windows Millennium Edition をご使用の場合

- ① " スタート " メニューから " 設定 "" コントロールパネル " を選びクリックする
- ②コントロールパネルの画面で、 "システム"のアイコンをダブルク リックする
- ③ " デバイスマネージャ " のタブをク リックする
 - "種類別に表示"にチェックが入っているか確認してください。
- ④デバイスが認識されていることを 確認する
 - "ユニバーサル シリアル バス コントローラ"の項目の中に"Net MD"が認識されていることを確認してください。



Windows 98/98 Second Edition の一例



Windows Millennium Edition の一例

デバイスが認識されていない場合は、USB ケーブルを抜き差ししてみてください。 それでも認識されない場合は、パソコンを再起動してください。

MD に録音する (チェックアウト)

準備

- ①パソコンの電源を入れ、OSを起動させる
- ②本機とパソコンを USB ケーブルで 接続する (➡ 58 ページ)
- ③本機に録音用の MD と充電式電池を 入れ、マルチクレードルに取り付ける MD の誤消去防止つまみを閉じておく。 (➡ 67ページ)



パソコンで Beat Jam を起動し、 録音したい曲(OpenMG 形式) を MD にチェックアウトする 詳しい操作については、Beat Jam の取扱説明書 15 ~ 23 ページを ご覧ください。


チェックアウトが終わると、



" UTOC Writing " 点灯後、録音が 終了します。



パソコンの曲にタイトルが付いている場合は、タイトルも MD に記録されます。



SP (通常ステレオ) /LP2/LP4 モードを設定するには

Beat Jam の " チェックイン / チェックアウト " 画面の " MD 録音モード " をクリックして選択します。

ステレオ長時間モード (LP) 曲のビットレートによって LP2 モードまたは LP4 モードに設定されます。 132 kbps/105 kbps の場合: LP2

66 kbps の場合; LP4 ステレオモード(SP)

曲のビットレートにかかわらず、通常 ステレオモードになります。 MD**LP** に対応していない MD 機器でも再生 できます。

(■ BeatJam 取扱説明書 22ページ)

お知らせ)

チェックアウト中の曲を本機で再生することはできません。

録音が終了すると、BeatJamの"デバイス/メディア"画面にチェックアウトした曲が表示され、曲がMDに録音されたことを確認できます。

パソコン上の音楽データに、再生期間、再生回数などの制限がある場合は、MD に録音できません。

゙ パソコンに戻す (チェックイン)

チェックアウトした曲を元のパソコンに戻すと、再び別のメディアにチェックアウトして使用できます。チェックインすると、MD内の曲は削除され、その曲のパソコン側での残りのチェックアウト回数が1回増えます。

準備

- ①パソコンの電源を入れ、OSを起動させる
- ②本機とパソコンを USB ケーブルで接続する (■ 58ページ)
- ③チェックアウトされた曲が録音されている MD と充電式電池を本体に入れ、マルチクレードルに取り付ける



パソコンで Beat Jam を起動して、曲をチェックインする 詳しい操作については、Beat Jam の取扱説明書 24 ~ 25 ページを ご覧ください。

チェックインが終わると、




" UTOC Writing " 点灯後、停止し 、ます。

押す

USB ON/OFF

302 3.43.

Net MD が終了します。



チェックアウト、チェックイン に関するお知らせ

曲間に全く無音部のない2曲をチェックアウトすると、MD では曲間にわずかな無音部が録音され、とぎれたように聞こえることがあります。このような場合、BeatJamの操作で2曲をつなげて1曲にしてからMDにチェックアウトすると、とぎれのない1曲として録音することができます。

MDのグループにチェックアウトしたときに、ディスク名、グループ名、タイトル名などの情報が多すぎた場合、エラー表示が出て曲がどのグループにも属さないかたちで録音されることがあります。チェックアウトした曲を本機の操作で ERASE/DIVIDE/COMBINE すると、パソコンにチェックインできなくなります。MOVE やタイトル編集は自由に行えます。

チェックアウトされたデータは、元 のパソコンにしか、チェックインでき ません。

パソコン上にチェックアウト元の曲が無い状態で(パソコン上で曲を削除したり、チェックアウト元以外のパソコンの場合)チェックインすると、MD内の曲は削除され、パソコンにも曲は戻らないのでご注意ください。

パソコンから本機の MD を操作する

MD の演奏

MD の編集

タイトルを編集する 曲を並べかえる(MOVE)

不要な曲を消す (ERASE)

詳しくは BeatJam の取扱説明書を ご覧ください。

編集が終わったら

本体の[ENTER, USB ON/OFF]を押して Net MD を終了します。

" UTOC Writing " 点灯後、編集内容 が MD に記録されます。

お知らせ

BeatJamの画面の[♠] (CD/メディアの取り出し) ボタンを押しても、本機から MDを取り出すことはできません。BeatJamで MDの全曲を削除した場合、ディスクタイトルの表示が更新されない場合があります。 MDの情報をパソコン側で表示するには、[ENTER, USB ON/OFF] を押して Net MD をいったん終了し、もう一度押して Net MD の状態にしてください。

Net MD使用中に操作できるボタン 音量調節ボタン

[VOL,-,+](本体)

[-, +] (リモコン)

[← −,+ ← , VOL/CURSOR]

(マルチクレードル)

音質切換ボタン

[EQ/REC SENS](本体)

[T.MARK/EQ](リモコン)

Net MD確立/終了ボタン

[ENTER, USB ON/OFF]

(マルチクレードル)

お知らせ

Net MDの状態でMDの録音や編集を行っているときに、ふたが開かない場合があります。ディスクを取り出すときは[ENTER, USB ON/OFF]を押して、いったん Net MDを終了してください。

お願い

チェックイン / チェックアウト中, 編集中は、次のようなことはしないでください。音楽データが壊れることがあります。

マルチクレードルの[▲, EJECT] を押して本機を取り外す USBケーブルを抜く 充電式電池を抜いたり、ACアダ プターを抜く

BeatJam や BeatStream を アンインストール(削除)する には

BeatJam 取扱説明書の 12 ページを ご覧ください。(Net MD USB ドラ イバーは削除されません。)

他の機器と組み合わせて使う

接続する機器の説明書をあわせてご覧ください。


本製品を正しく動作させるために、別売り品は必ず当社指定のものをお使いください。当社指定以外のものをお使いになると、故障の原因になります。

ステレオ機器と接続する

本機の再生音を、ステレオ機器で聞いたり、録音したりすることができます。 下記の別売り品をお買い求めください

接続コード

ステレオ機器側がライン入力端子の場合: RP-CAPM3G15、1.5 m ステレオ機器側がミニホンジャックの場合: RP-CAM3G15、1.5 m



(お知らせ)

ステレオ機器へは、必ず入力端子に接続してください。誤って出力端子に接続 すると、本機が故障するおそれがあります。

音質の設定は、NORMAL (解除)にしてください。(➡ 34 ページ) 本機の音量レベルは 20 ~ 23 に設定してください。

別売り品の紹介

別売り品の品番は、2002年5月現在のものです。品番は変更されるこ 他とがあります。

接続コード

アナログ

RP-CAPM3G15

ステレオミニプラグ ピンプラグ

長さ: 1.5 m RP-CAM3G15

ステレオミニプラグ ステレオミニプラグ

長さ: 1.5 m 光**デジタル** RP-CA2110A

光角形プラグ 光ミニプラグ

長さ: 1m RP-CA2210A

光ミニプラグ 光ミニプラグ

長さ: 1m

ステレオインサイドホン

RP-HJ337 RP-HJ237

ステレオマイク

RP-VC200(プラグインパワー方式)

RP-VC300

ニッケル水素充電式電池

HHF-1PSC/1B HHF-AZ01S/1B

使用上のお願い

本体

以下のことは故障の原因となりますので、避けてください。

強い衝撃や落下

雨に濡らす

風呂場など湿気が多いところでの使用 倉庫などほこりが多いところでの使用 暖房器具の近くなど温度が高いとこ ろでの使用

ステレオインサイドホン 本体に巻き付けるときは、コードにた るみを持たせてゆるく巻いてくださ い。 お手入れ

本体が汚れたら

柔らかい布でふいてください。 ひどい汚れは、薄めた台所用洗剤(中性)を含ませた布でふき、後は、から ぶきしてください。

推奨品: クリーニングクロス(VUA7091) (サービスルート扱い)

アルコールやシンナーは使わないで ください。

化学ぞうきんをご使用の際は、その 注意書に従ってください。

良い音でお楽しみいただくために 別売りの専用クリーナーで時々清掃さ れることをおすすめします。

推奨品: MD レンズクリーナー (品番: RP-CL310)

MD 録音ヘッドクリーナー (品番: RP-CL320)

MD について

MDの種類

再生専用 MD



ピットという小さなくぼみの有無 でデータが記録されています。CD と同様の、この方式の MD を「光 ディスク」といいます。


録音用 MD



磁気によってデータが記録されま す。この方式の MD を「光磁気デ ィスク」といいます。

取扱上のお願い

指定外の場所にラベルを貼らない (また、ラベルやテープの糊がはみ 出したり、はがしたあとのある MDは、故障の原因になりますの で、機器に入れないでください。) シャッターは開けない



(万一開いてしまったときは、すぐ に閉じてください。中の円盤には 直接手を触れないでください。)

MDの用語解説

トラックマーク

録音部分に記録される「区切り」 のことです。ある区切りから次の 区切りまでが1曲と数えられます。 本機では次のような方法でトラッ クマークをつけることができます。 オートマークモード

レコーダー自体が自動的に曲の変 わり目を判断して、トラックマー クをつけていきます。

マニュアルマークモード お好みの場所に、手動でトラック マークをつけることができます。 タイムマークモード

ある一定時間の間隔でトラックマ ークを自動的につけることができ ます。(会議などをこの方法でマイ クを使って録音すると、一定時間 の間隔で頭出しができます。)

TOC(Table of Contents) 音楽信号とは別に、MDに記録さ れている情報のこと。曲数、総再 生時間、MDのタイトル、曲名な どをいいます。

UTOC(User Table of Contents) 使用者の利用状況に応じて書き込 まれたり、置き換えられたりする TOC 情報のこと。MD の編集結果 や、タイトル、曲名などの UTOC 情報がMDに書き込まれるとき、 本機は "UTOC Writing "と表示 して注意を促します。

MDの録音・編集について

MD の録音方式

デジタル接続

CD、MD などのデジタル機器(光 出力端子のある機器)をデジタル 接続したときの録音

デジタル信号をそのままデジタル で録音します。ただしこの録音に は SCMS という制限があります。 (右記参照)

アナログ接続

- ①CD、MDなどのデジタル機器を アナログ接続したときの録音 デジタル信号#アナログ信号#デ ジタル信号と順に変換して録音し ます。
- ②ラジオやテープなどアナログ機 器の録音


アナログ信号をデジタル信号に変 換して録音します。

録音をお楽しみいただくには、デ ジタル、アナログそれぞれの接続 方式専用の接続コードをお買い求 めください。(➡ 18、19ページ)

デジタル録音の制限について (SCMS)

デジタル録音には、SCMS(シリ アル・コピー・マネージメント・ システム)という制限があります。 光デジタルケーブルを使って他の デジタル機器から本機に録音する と、信号劣化の少ないクリアなデ ジタル録音が行なえます。そこで 著作権保護のため、この MD から さらに別の MD にはデジタル録音 できないようになっています。 なおアナログ録音には、このよう なしくみはありません。

大切な録音を消さないために 誤消去防止つまみを、穴が開く方 向にずらします。(新たに録音、編 1.1 集するときは閉じてください。)



558

著作権について

あなたが録音したものは、個人として楽しむなどのほかは、著作権法上権利者に無断で使用できません。なお、この商品の価格には、著作権法の定めにより、私的録音補償金が含まれております。

お問合せ先:

著作権について

放送やレコードその他の録音物 (ミュージックテープ、カラオケ テープなど)の音楽作品は、音 楽の歌詞、楽曲などと同じく、 著作権法により保護されていま す。

従って、それらから録音した MDやテープを売ったり、配っ たり、譲ったり、貸したりする 場合、および営利(店のBGM など)のために使用する場合に は、著作権法上、権利者の許諾 が必要です。

使用条件は、場合によって異なりますので、詳しい内容や申請、その他手続きについては、「日本音楽著作権協会」(JASRAC)の本部または最寄りの支部にお尋ねください。

日本音楽著作権協会

本部 (03)3481-2121

北海道支部 i (011)221-5088

盛岡支部 (019)652-3201

仙台支部 i_(022)264-2266

長野支部

i (026)225-7111 大宮支部

i (048)643-5461 上野支部

(03)3832-1033

東京支部

(03)3562-4455

西東京支部 (03)3232-8301

東京イベントコンサート支部

i (03)5286-1671 立川支部

i (042)529-1500

横浜支部 i (045)662-6551

静岡支部 i (054)254-2621

中部支部

i (052)583-7590 北陸支部

i (076)221-3602 京都支部

i (075)251-0134

大阪支部 i (06)6244-0351

神戸支部

i (078)322-0561 中国支部

i (082)249-6362 四国支部

i (087)821-9191 九州支部

i (092)441-2285 鹿児島支部

i (099)224-6211 那覇支部

i (098)863-1228

MD のシステム上の制約

MDは、カセットテープや DAT とは異なる方式で録音が行われます。この方式には、いくつかの制約があるため、次のような症状が出る場合があります。これらは、故障ではありません。

こんなときは

このような制約が

り、実際に録音できる時間が少な

くなることがあります。

270 0.2 2.10	
ディスクの最大録音時間に満たな いのに、" UTOC FULL " が表示 される。	録音時間に関係なく、254曲まで録音すると、それ以上録音できません。
曲数や録音時間が最大ではないのに、" DISC FULL "が表示される。	録音、編集をくり返した MD や、 MD に傷がある場合、録音できな くなることがあります。
編集で、曲と曲がつなげない場合がある。	録音、編集をくり返した MD や、 録音モード(通常、モノラル、 LP2、LP4)が異なる曲どうし ではコンバインできません。
曲を消しても残り時間が増えない。	MDの録音残り時間を表示するとき、12秒以下の部分は無視されます。このため短い曲を何曲消しても録音時間が増えないことがあります。
早送り、早戻しをすると、音が途 切れることがある。	録音、編集をくり返した MD に録音すると、1 つの曲が分断されて記憶されることがあるため、このようなことが起こります。
録音した時間と残り時間を足して も、ディスクの最大録音可能時間 にならない。	MDは2秒以下の音声を録音する にも、約2秒間のディスク領域を 使うため、表示される残り時間よ

故障かな!?

修理を依頼される前に、この表で症状を確かめてください。なお、これらの処置をし ても直らない場合や、この表以外の症状は、お買い上げの販売店にご相談ください。

|--|

CNACE		处且	(ページ)
操作できない	ホールド状態になってい ませんか。	ホールド状態を解除する。	16
	ディスクが入っています か。	ディスクを入れる。	17
	AC アダプターが正しく 接続されていますか。	ACアダプターを接続し 直す。	13
	電池が消耗していません か。	充電する。または乾電池 を交換する。	13、15
	損傷しているディスクが 入っていませんか。	別のディスクに取り替え る。	
再生できない	録音したディスクが入っ ていますか。	曲の入っているディスク に取り替える。	_
1 曲目から再 生できない	再生モードがランダムに なっていませんか。	ランダム再生モードを解 除する。	36
	グループモードになって いませんか。	グループモードを解除す る。	35
録音や編集ができない	再生専用ディスクが入っ ていませんか。	録音用ディスクに取り替える。	_
	ディスクが誤消去防止状 態になっていませんか。	ディスクの誤消去防止つ まみを閉じる。	67
	他の機器と正しく接続さ れていますか。	正しく接続し直す。	18 ~ 19
	外部機器の光出力から信 号が出ていますか。	外部機器の取扱説明書を 読んでください。	_
スピーカー から音が出 ない	充電式電池だけで使用し ていませんか。	AC アダプターも接続し てください。電池だけで は音が出ません。	16、30

インサイド ホンから音	音量が最小になっていま せんか。	音量を調節する。	29
が出ない 雑音がする	インサイドホン、リモコ ンのプラグは奥まで入っ ていますか。	一度抜いて、再度差し込 む。	29
	プラグが汚れていませんか。	プラグをきれいにふく。	
	本機と携帯電話を近づけ て使っていませんか。	本機から携帯電話を離す。	
ディスク名、 曲名が途切 れたり、表 示されない	ディスクに記録できる文 字数を超えていませんか。	文字数の少ない名前につ け直す。	50 ~ 53
本 体 の ふ た が開かない	電池が消耗したり、AC アダプターの接続が外れ ていませんか。	新しい電池に取り替える。 または、ACアダプター を正しく接続する。	13 ~ 15
	パソコンと接続中(Net MD の状態)になってい ませんか。	マルチクレードルの[ENTER, USB ON/OFF]を押して、 Net MDを終了する。	61 ~ 63
イントロス キャンメモ リー再生が できない	グループモードになって いませんか。(グループモ ードではできません。)	リモコンの[PLAY MODE]を長押しして、 ディスクモードにする。	35
本体をマル チクレード ルに取り付	本体に充電式電池が入っていますか。	本体に、充電式電池を入 れる。AC アダプターだけ では動きません。	14
けると動か ない	本体がマルチクレードル に正しく取り付けられて いますか。	正しく取り付ける。	13
	本体のクレードルとの接 続端子が汚れていません か。	接続端子の汚れをきれい にふく。	_

故障かな!?(つづき)

こんなとき	ここをチェック	処置	参照ページ
パソコンに 接続してい るい	本機がパソコンに認識されていますか。	以下を確認してください。 ①USBケーブルが正しく 接続されているか ②必要なアプリケーショ ンソフトとドライバー がインストールされて いるか ③本体がマルチクレード ルに正しく取り付けら れているか ④マルチクレードルの [ENTER, USB ON/OFF] を押して、"Net MD" が表示されるか	58 57 ~ 60 13 61 ~ 63
音が途切れ る。パソコ ンの画面が かたまる。	音楽再生用ソフト以外の ソフトを開いていません か。	音楽再生用ソフト以外の ソフトを閉じる。	
Net MDで 録音中に音 が出ない。	チェックアウト中は再生 音が聞こえません。	録音終了後 MD を再生し て曲を確認する。	
付属アプリ ケーション ソ フ ト BeatJamを インストー ルできない。	ご 使 用 の パ ソ コ ン は BeatJam の使用に必要 な環境を満たしています か。	BeatJam は必要な環境 を満たした Windows OS のパソコンでのみ使 用できます。詳しくは BeatJam の取扱説明書 をご覧ください。	_

Q&A(よくあるご質問)

Q (質問)	A (回答))(参照 ページ
----------	--------	----	-----------

録音した曲に上書きで録音したい。	上書き録音はできません。MDの 録音残り時間が少ない場合はイレ ース機能で不要な曲を消してから 録音してください。	44
一度録音した MD に追加で録 音したい。	自動的に前の録音部分の続きから 録音しますので、そのまま録音し てください。	21
録音中に、音量を変えたらどうなる?	録音中に音量を調節しても、録音 される音には影響しません。	_
ステレオ / モノラル / MDLP 再 生はどうやって切り換えるの?	録音された状態によって、自動的 に切り換わります。	28
MD LP 長時間録音された MD はどの機種でも再生できるの?	MD LP に対応していない機種では再生できません。曲のタイトルの頭に"LP:"と表示され無音状態になります。	_
スピーカーに L、R の表示が無いのですが?	付属のスピーカーには L (左) R (右)の区別はありません。左に置いたほうを L 端子に、右に置いたほうを R 端子に、接続してください。	16
漢字とひらがなは入力できるの?	本機では漢字、ひらがな(全角文字領域)の入力はできません。付属のアプリケーションソフト BeatJam を使って入力してください。	
パソコンから録音するときに、 MD LP 長時間録音はできる の?	Beat Jam で設定できます。 "LP"を選び、曲のビットレート で 132 kbps/105 kbps を選ぶ と LP2 で、 66 kbps を選ぶと LP4 で録音されます。"SP"を選 ぶと通常ステレオ録音になります。	61

表示
意味
処置

BLANK DISC [BLANK]	ディスクに音楽や文字情報が 記録されていません。	再生するときは、録音済みのディスクに取り替えてください。				
Can't COMBINE	コンバインできない曲をまと めようとしました。	M D のシステム上の制約で す。				
Can't COPY (SCMS)	デジタル入力録音でコピーの コピーは作れません。	アナログ入力を使って録音し てください。				
Can't DIVIDE	ディバイドできない曲を分け ようとしました。	MDのシステム上の制約で す。				
Can't EDIT [ERROR]	① タイトルのコピー(タイト ルステーション)ができませ ん。② グループ編集ができま せん。	①コピーできる条件を満たしているディスクを入れてください。②グループの状態を確認して再度実行してください。				
DIGITAL UNLOCK	デジタル (光) 入力端子につ ながずに録音しようとしまし た。	オプティカルデジタルケープルの接続を確認してください。また、録音もとの機器の電源が、ONになっているか確認してください。				
DISC FULL [FULL]	MDに録音できる空きがあり ません。	不要な曲を消すか、他の MD に取り替えてください。				
DISC PROTECT	MD が誤消去防止状態になっ ています。	MDの誤消去防止つまみを閉じた状態にしてください。				
EMERGENCY STOP	録音中に異常が発生しました。	MDを入れ直してください。				
F17	磁気ヘッドに異常があります。	販売店に、ご相談ください。				
GROUP DATA FULL	グループ管理データを更新す る領域がありません。	グループを解除するか、グループ タイトルを削除してください。				
HOLD	HOLD 状態になっています。	HOLD 状態を解除してください。				
LOW BATTERY U01 [U01]	充電式電池や乾電池の残量が 無くなりました。	充電するか、乾電池を交換し てください。				

]内は、リモコンの表示です。

意味

18/1	思州	
NO BATTERY [NO BAT]	本体に充電式電池を入れずにマル チクレードルに取り付けました。	充電式電池を入れてくださ い。
NO DISC [NoDISC]	MD が入っていません。	MDを入れてください。(入れても表示される場合は販売店にご相談ください。)
PLAYBACK DISC [ERROR]	再生専用 MD を録音・編集し ようとしました。	録音用 MD に取り替えてください。
SYSTEM ERROR [ERROR]	自己診断により故障と判断し ました。	お買い上げの販売店にご相談 ください。
TOC ERROR [ERROR]	MDに異常があるか、損傷し ています。	オールイレース機能で全曲消すか、MDを取り替えてください。
TOC Reading [T-READ]	M D の情報を読み込み中で す。	
TrackNO NOT SAME	読み込んだタイトル数と、コピ ー先 MD の曲数が異なります。	タイトルと曲の数を同じにし てコピーしてください。
TITLE FULL [ERROR]	入力しているタイトルが規定 の文字数を超えています。	入力可能な文字数で入力して ください。(➡ 51ページ)
TITLE OVER [ERROR]	既に 101 文字以上入力されている タイトルを編集しようとしている。	編集を続けると101文字以 降は自動的に削除されます。
TRACK PROTECT	曲にプロテクト (保護)がか かっています。	編集・消去していいか確認し てから操作してください。
	パソコンからチェックアウト した曲を編集しようとしまし た。	パソコンからチェックアウトし た曲を編集すると、パソコンに チェックインできなくなります。
UTOC FULL [FULL]	録音曲数が最大(254曲)になっているので録音できません。	不要な曲を消すか、新しい録音 用 M D に取り替えてください。
	録音曲数は最大ではありませんが、MD のシステム上の制約で録音できません。	
	タイトルを書き込めるだけの領 域の空きがありません。	
UTOC Writing [WRITE]	UTOC に書き込んでいます。	

処置

保証とアフターサービス

(よくお読みください)

修理・お取り扱い・お手入れ などのご相談は... まず、お買い上げの販売店へ お申し付けください

転居や贈答品などでお困りの 場合は...

社の「修理ご相談窓□」へ!

修理は、サービス会社・販売会

その他のお問い合わせは、「お 客様ご相談センター」へ! 保証書(裏表紙をご覧ください) お買い上げ日・販売店名などの 記入を必ず確かめ、お買い上げ の販売店からお受け取りくださ い。よくお読みのあと、保存し

保証期間 : お買い上げ日から本体1年間

てください。

補修用性能部品の保有期間 当社は、ポータブル MD レコ ーダーの補修用性能部品を、製 造打ち切り後8年保有してい ます。

注)補修用性能部品とは、その 製品の機能を維持するため に必要な部品です。

修理を依頼されるとき

70ページの「故障かな!?」の表 に従ってご確認のあと、直らない ときは、まず AC アダプターを抜 いて、お買い上げの販売店へご連 絡ください。

保証期間中は

保証書の規定に従って、お買い 上げの販売店が修理させていた だきますので、恐れ入りますが、 製品に保証書を添えてご持参く ださい。

保証期間を過ぎているときは 修理すれば使用できる製品につ いては、ご希望により有料で修 理させていただきます。

修理料金の什組み

修理料金は、技術料・部品代・ 出張料などで構成されています。

技術料は、診断、故障個所の修 理および部品交換・ 調整・修理完了時の 点検などの作業にか かる費用です。

部品代 は、修理に使用した部品お よび補助材料代です。

出張料は、製品のある場所へ技 術者を派遣する場合 の費用です。

	ご連絡いただきたい内容							
品名	品名 ポータブル MD レコーダー お買い上げ日 年 月 日							
品番	SJ-MR250	故障の状況	できるだけ	り具体的	匀に			

使いかた・お買い物などのご相談

ナショナル/パナソニック お客様ご相談センター

電話 マメート 👀 0120-878-365

FAX 79- 00 0120-878-236

365日/受付9時~20時

Help desk for foreign residents in Japan

外国人/海外仕様商品(ツーリスト商品他)等ご相談窓口 Tokyo (03) 3256 - 5444 Osaka (06) 6645 - 8787

Open: 9:00 - 17:30 (closed on Saturdays/Sundays/national holidays)

修理に関するご相談

ナショナル/パナソニック 修 理 ご 相 談 窓 口

ナビダイヤル(全国共通番号) 20570-087-087

お客様がおかけになった場所から最寄りの修理ご相談窓口につ ながります。呼出音の前にNTTより通話料金の目安をお知らせ します。

携帯電話・PHS等からは最寄りの修理ご相談窓口に直接おか けください。

最寄りの修理ご相談窓口は、以下をご覧ください。

		北	海	道	地	X		
札幌	札幌市厚別区厚別 南2丁目17-7 公(011)894-1251	帯広	1丁	市西 目 7-1 0155	1	-	函館	函館市西桔梗 589番地241 (函館流通卸
旭川	旭川市2条通21丁目 左1号 ☎(0166)31-6151							センター内) 雷 (0138)48-6631

		東	北	地	X		
青森	青森市第二問屋町 3-7-10 ☎ (017)739-9712	岩手	盛岡市3 30-3 雷 (019			山形	山形市流通センター 3丁目12-2 ☎ (023)641-810
秋田	秋田市御所野湯本 2丁目1-2 ☎ (018)826-1600	宮城	仙台市第 7-4-18 雷 (022			福島	福島県安達郡本宮町字南/内65 (0243)34-130

保証とアフターサービス(つづき)

ナショナル/パナソニック 修 理 ご 相 談 窓 口

		首	都 [巻	地	X		
栃木	宇都宮市御幸町 194-20 ☎ (028)689-2555	埼玉 千葉	桶川市 公(04 千葉市	48)7	28-8		山梨	甲府市下飯田2丁目 1-27 雷 (055)222-5171
群馬	高崎市大沢町229-1 (027)352-1109		星久喜	町1 43)2	72 08-6	034	神奈川	横浜市港南区日野 5丁目3-16
水戸	水戸市柳河町309-2 雷 (029)225-0249	東京	東京都 宮坂2	丁目:	26-1	7 78∩	新潟	☎ (045)847-9720 新潟市東明1丁目
つくば	つくば市花畑2丁目 8-1 ☎ (0298)64-8 7 56		LA (O.	J/J 4	113	, 00		8-14 1 (025)286-0171

		中	部	地	\overline{x}		
石川 富山	石川県石川郡 野々市町稲荷 3丁目80 ☎(076)294-2683 富山市寺島1298	長野静岡	7600- 合(026 静岡市西	大字笹賀 7 63)58-0 5島765 1)287-9		岡崎 岐阜	岡崎市岡町南久保28 (0564)55-5719 岐阜県本巣郡北方町 高屋太子2丁目30 (058)323-6010
福井	本 (076)432-8705 福井市開発4丁目 112 本 (0776)54-5606	名古屋	名古屋市 塩入町 8 ☎ (052		225	高山三重	高山市花岡町3丁目82 (25) (0577)33-0613 久居市森町字北谷 1920-3 (059)255-1380

		近	畿	地	$\overline{\times}$		
滋賀	守山市勝部6丁目 2-1	大阪	大阪市	-7		和歌山	和歌山市中島499-1 (073)475-2984
京都	☎ (077)582-5021 京都市南区上鳥羽	奈良	☎ (06) 大和郡।			兵庫	神戸市中央区 琴/緒町3丁目2-6
	石橋町20-1 ☎ (075)672-9636		4 0 4 - 2 23 (07		2770		1 (078)272-6645

ナショナル/パナソニック 修 理 ご 相 談 窓 口

		中	===	地	X		
鳥取	鳥取市安長295-1 ☎ (0857)26-9695	出雲		渡橋町4 53)21-		広島	広島市西区南観音8丁目13-20
米子	米子市米原4丁目 2-33 ☎ (0859)34-2129	浜田	浜田市 327-9 ☎ (08		6629	山口	☎ (082)295-5011 山口市鋳銭司 字鋳銭司団地北
松江	松江市平成町 182番地14 雷 (0852)23-1128	岡山	矢尾80	都窪郡早) 7 6)292-			ង47-23 ភ (083)986-4050

		끄	===	地	X		
香川徳島	高松市勅使町152-2 亞 (087)868-9477 徳島県板野郡北島町	高知	331-1	岡豊町中 8)866-3	-	愛媛	松山市土居田町 750-2 ☎ (089)971-2144
1花 云	福島宗教野都北島町 鯛浜字かや108 ☎ (088)698-1125						

		九	州	地	X		
福岡	春日市春日公園 3丁目48 ☎(092)593-9036	大分	8-35	荻原4丁 7)556-3		天草	本渡市港町18-11 公 (0969)22-3125 鹿児島市与次郎
佐賀	佐賀市本庄町大字 本庄896-2 ☎ (0952)26-9151	宮崎	宮崎県第 下加納3 ☎(09)			大島	1丁目5-33 雷 (099)250-5657 名瀬市矢之脇町10-5
長崎	長崎市東町1949-1 25 (095)830-1658	熊本		建軍本町 6)367-6		八曲	西 (0997)53-5101

	沖	縄	地	X
沖縄	浦添市城間4丁目23-11	23 (09	98)877-	1207

所在地、電話番号が変更になることがありますので、あらかじめご了承ください。

0102

Supplied Accessories

Refer to the illustration on page 9 of the Japanese text.

- Stereo earphones
- Wired remote control
- Nickel-metal hydride rechargeable battery
- External battery case
- Carrying case
- AC adaptor
- Multi cradle
- Speakers
- USB cable
- Net MD Software

Location of Controls

Refer to the illustrations on pages 10 to 12 of the Japanese text.

- ■Main unit
- 1 Display
- ② Open switch (OPEN)
- ③ Tone/recording sensitivity button (EQ/REC SENS)
- Play and record mode Japanese syllabary/ Chinese character select button (MODE)
- (5) Track mark mode button (MARK MODE)
- ⑥ Volume buttons (VOL − +)
- (PLUG IN POWER)]
- Optical digital in/line in jack (OPT/LINE IN)
- Headphone jack (Ω)
- (i) Hold switch (HOLD→)
- ① Play/record/pause/power on button (►/II)
- ② Recording level control, skip/search buttons (|◄◄, ▶►|)
- ③ Stop/operation off button (/OPR OFF)
- Recording pause/power on/LP recording switch (REC/LP MODE→)
- (5) Rechargeable battery compartment cover (◀ OPEN)
- (6) Multi cradle connection terminal
- (17) Connection terminal for battery case
- ■Multi cradle
- Eject button (▲, EJECT)
- ② Edited contents set, Net MD start up button (ENTER, USB ON/OFF)
- ③ Character delete button (DELETE)
- Entering/canceling editing mode button (EDIT)
- (5) Main body attachment hook
- 6 Main body attachment terminal
- Numbers/characters buttons
- ® Character type button (CHARA)
- (9) Space or symbol button (SPACE)

- Volume control, edit menu select, track number select, cursor movement buttons (← −, + →, VOL/CURSOR)
- ① DC IN jack (DC IN 4.5 V ♦-ⓒ-♦)
- 12 USB terminal
- (3) Speakers (8 Ω), R/L
- ■Main unit display
- (1) Battery indicator
- 2 Group mode indicator
- 3 Recording indicator
- 4 LP recording indicator
- (5) Synchronized recording indicator
- Remaining recording/playing time indicator
- 7 Track number, Time display
- ® Level meter
- 10 Text
- 1 Sound quality indicators
- Play mode indicators
- ■Remote control
- 1 Display
- ② Hold switch (HOLD ▶)
- ③ Skip/search buttons ([◄◄, ▶►])
- 4 Volume buttons (+, -)
- ⑤ Play/record/stop button (►/■)
- 6 Earphone iack
- 7 Clip
- (9) Play mode button (PLAY MODE)
- Track mark/tone control button
- (T.MARK/EQ)
- ① Plug
- ■Remote control display
- 1) Text
- ② Group mode indicator
- ③ Recording indicator
- Battery indicator
- (5) Play mode indicator
- 6 Sound quality indicators
- 7 Disc mark
- ® Track number
- ■Stereo earphones
- 1) Plug
- ② Slider

Slide up to prevent tangling the cord when the earphones are not in use.

Power Supply

Refer to the illustrations on pages 13 to 15 of the Japanese text.

The rechargeable battery

- 1 Put the battery into the unit.
- 2 Install the unit to the multi cradle.
- 3 Connect the AC adaptor to the multi cradle.

Recharging begins.

"CHARGE" appears on the display while recharging.

"CHARGE" disappears when the battery is fully charged. It takes approximately 3.5 hours to recharge the supplied battery.

■When recharging is over

Note

Use only the supplied AC adaptor. Use of other adaptors can damage the unit.

■To remove the main unit from the multi cradle

Press [A, EJECT].

Be sure there is a rechargeable battery in the unit when you use the unit installed on the multi cradle. The unit will not run off the AC mains without a battery. If you install the unit on the multi cradle without inserting the battery, "NO BATTERY" will be displayed.

■Recharging time and duration

(When using the supplied battery.)

Charging: Approx. 3.5 hours

Play time
Normal stereo mode : Approx. 25 hours

LP2 stereo mode: Approx. 33 hours **LP4 stereo mode**: Approx. 40 hours

Recording time

Normal stereo mode: Approx. 13 hours LP2 stereo mode: Approx. 17 hours LP4 stereo mode: Approx. 21 hours

- Duration may be reduced under some conditions.
- If the unit is to be used for long periods, such as during recording, use the AC adaptor to power it.

■Rechargeable number of times

The battery can be recharged approx. 300 times. The battery has reached the end of its lifetime once play time is dramatically reduced even after full recharging.

■Replacement

Nickel-metal hydride rechargeable battery (HHF-1PSC/1B, HHF-AZ01S/1B).

Note

- If the unit is not to be used for a long time disconnect the AC adaptor from the AC outlet and turn the unit off to save power.
- If using the unit while it is installed on the multi cradle, ensure that it is aligned correctly, and that it is not forced into position or subjected to violent treatment.
- The unit cannot recharge batteries other than the one supplied or recommended replacements.
- It is not necessary to completely discharge Panasonic's nickel-metal hydride rechargeable batteries before recharging them.
- The unit can only be recharged while it is off.
- •The AC adaptor and battery may become warm during recharging but this is normal.
- •When using for the first time in a long time you may find that the batteries do not recharge to the original level. If you repeat the charging/depleting process the batteries will return to normal.

Dry cell battery (not included)

Use one LR6 alkaline battery. Use long -life Panasonic alkaline batteries

- 1 Put the battery into the battery case.
- 2 Attach the case to the unit.

■For longer use

Use the two types of batteries at the same time.

The battery indicator

The indicator flashes when the battery is almost flat. Recharge or replace the battery.

Note

- The unit may make some noise when the AC adaptor is connected to the multi cradle with the unit installed or when batteries are first installed. This is normal.
- When recording, we recommend that you place the unit WITH BATTERY INSERTED on the multi cradle and connect the AC mains.
- Always use rechargeable batteries in combination with normal dry cell batteries to avoid fast depletion of the dry cell batteries and to safeguard against loss of power partway through recording.

Setting the speakers

Refer to the illustration on page 16 of the Japanese text.

Attaching speakers to the multi cradle

There is no differentiation made between the speakers regarding left and right. Just connect the speaker you place on the left to the terminal on the left and similarly for the speaker on the right.

- •Make sure that there is a rechargeable battery in the unit before you place it on the multi cradle and connect the AC mains. No sound will be produced from the speakers if you are using only a battery.
- Do not connect speakers other than those provided. Also, do not connect the speakers provided to other
- Speakers are easily affected by magnetic fields so avoid placing cash cards and travel cards nearby.

The HOLD Function

Refer to the illustration on page 16 of the Japanese text.

This function stops the unit and remote control from responding when a button is pressed.

Guards against the following

- The unit is powered on accidentally when not in use. causing the batteries to run down.
- •A button is accidentally pressed during play or recording, interrupting the operation.

There is a HOLD switch on both the unit and remote control, each of which works independent of the other.

■The "HOLD" display

This is displayed for a few seconds on the main unit's and the remote control's display panels when the following occurs.

- The main unit is on hold and a button is pressed. (When off, display appears only if [► / II] or [REC/LP MODE →] is operated.)
- The remote control's switch is moved to hold.

Insert an MD

Refer to the illustration on page 17 of the Japanese text.

- 1) Slide [OPEN] in the direction of the arrow to open the lid.
- 2 Slide the MD between the guides so it clicks into place.
- ③ Now close the lid.

The unit will come on and read the information after you insert the MD. If no operation is carried out for a minute the unit turns itself off automatically.

The title of the disc and song is shown. The title scrolls if it can not be displayed all at once. "BLANK DISC" is displayed when you insert a blank MD.

Removing the disc

Slide [OPEN] in the direction of the arrow and the disc springs out from the unit.

Basic recording

Refer to the illustrations on pages 20 to 24 of the Japanese text.

Preparation

- Release HOLD
- •Insert the rechargeable battery into the unit.
- Insert a recordable MD.

Connect this unit to a unit that has a digital output terminal.

ANAL OG

Connect this unit to a unit that has stereo LINE OUT terminals.

- Connect while the unit is stopped.
- •Do not connect anything to [MIC (PLUG IN POWER)] when analog recording.
- 2 Slide [REC/LP MODE →1 to the right.

The unit comes on and enters the recording standby mode.

To record at the correct volume

Adjust the recording sensitivity to suit the equipment you have connected. (See page 85.)

3 Slide again [REC/LP MODE →] to select the recording mode.

The mode changes each time you slide the button.

LP2: LP2 stereo mode	(
LP4 : LP4 stereo mode	
; No indication : Normal st	tereo mode

The recording times for each mode are as follows when you use an 80-minute MD.

LP2 stereo mode: Max.160 minutes LP4 stereo mode: Max.320 minutes

- 4 1 Press [►/II] to start recording.
 - 2 Begin playback of the source.

If you have inserted an MD with recordings already on it, recording starts from the first available space.

■To pause recording

Press [►/II]. (The number of tracks increases by one.)

Recording restarts when pressed again.

■To stop recording Press [OPR OFF].

(UTOC is recorded.)

- •The unit powers itself off automatically in about a minute.
- You can turn off the unit by pressing again [■/OPR OFF] on the main unit while stopped.

■Making good recordings

- •It is best to run the unit off the AC mains as much as circumstances of use permit. The unit should always have a rechargeable battery on board when being run off the AC
- Do not press [▲, EJECT] on the multi cradle while recording.
- •Do not open the lid or shake the unit while recording. Be especially careful while "UTOC Writing" is on the display. If the unit is moved at this time, the recording may not be correctly recorded onto the disc.
- •You can damage the unit or disc if you try to force open the lid.

■High quality recording

You can take advantage of the unit's High Density Encoding System (HDES) when using normal stereo mode for recording, whichever input mode you choose to use: digital, analog. or microphone.

HDES does not function when you use MDLP modes. "HDES" appears on the unit's display when you put the unit in the recording standby mode.

Synchronized recording

Synchronized recording

This method starts and stops recording at the same time as the source being recorded.

One track synchronized recording

The first track on a CD is recorded and then the unit goes to recording standby mode. This is a convenient mode if you want to record the first track off a number of single CDs.

Preparation

- Release HOLD.
- •Insert the rechargeable battery into the unit.
- •Insert a recordable MD.
- 1 Connect this unit to other equipment.
- 2 Slide [REC/LP MODE→] to the right. Slide again the switch to select LP2/LP4.
- 3 Press [MODE] to select the recording mode.

Each time the button is pressed

DIGITAL

SYNC > SYNC 1 > Normal (No display)

SYNC > Normal (No display)

If you have set the recording mode to "SYNC". recording begins immediately if the source, for example the radio, you are recording is already plaving.

4 Begin playback of the source.

Recording begins automatically.

■To pause recording

If you have selected

Synchronized recording (SYNC)

This unit automatically pauses if the source is stopped or if 2 seconds of silence when analog recording, 7 seconds of silence when digital recording is detected. (The number of tracks increases by one.)

 One track synchronized recording (SYNC 1) The unit automatically pauses after the first

track finishes (The number of tracks increases by one.)

Recording restarts as follows

- Synchronized recording (SYNC) When sound is input again
- One track synchronized recording (SYNC 1) When you change the CD and play track 1

■To stop recording Press [■/OPR OFF].

(UTOC is recorded.)

- The unit powers itself off automatically in about a minute.
- •You can turn off the unit by pressing again [/OPR OFF] on the main unit while stopped.

Note

- One track synchronized recording does not function in the following cases:
- 1)When you start CD play from track 2 or
- (2)When the first track on a CD is not numbered 1 (on the second of a set of two CDs. for example).
- You cannot pause recording manually during synchronized and one track synchronized recording.
- You cannot use synchronized recording when using a microphone.
- The beginnings of tracks may be cut-off when you use synchronized recording. Use normal recording if this occurs.

■Putting track marks

Track marks are put automatically as follows.

DIGITAL

When recording from a CD or MD

The track marks are put onto the MD corresponding to the tracks on the other disc. (Track marks may not correspond to track numbers with some discs.)

When recording from other digital sources

2 seconds of silence is determined as the division between two tracks and a track mark is added.

ANALOG

2 seconds of silence is determined as the division between two tracks and a track mark is added.

Note

Track marks will not be added if the space between tracks is short or if there is noise in the space. Track marks may be added in error if there is a silent or especially quiet portion in a track. Use the editing functions after recording to add and remove track marks. (See pages 90 to 91.)

■Connecting digital equipment

- •Use an AC adaptor to power a portable CD player and turn off its anti-skip function.
- This unit has a sampling rate converter that functions automatically, so you can make digital recordings from equipment with different sampling rates, such as satellite receivers and DAT decks.

■Note for long play recording

- You can record using normal stereo, LP2 stereo, and LP4 stereo on the same disc.
- "LP:" is added to the beginning of titles recorded with LP2 or LP4 but this is not displayed on this unit.
- LP4 mode uses a special compression method in order to achieve extended recording and this may rarely cause some noise when recording some material. Use standard stereo or LP2 mode for better sound quality.
- The mode reverts to normal stereo recording when you replace the battery or unplug the AC adaptor.

Recording from a microphone

Refer to the illustration on page 25 of the Japanese text.

Preparation

- Release HOLD.
- •Insert the rechargeable battery into the unit.
- Insert a recordable MD.
- 1 Connect the microphone.
- Connect while the unit is stopped.
- Do not connect anything to [OPT/LINE IN].
- •Keep the microphone away from the unit to avoid recording sounds from it.
- If howling occurs while you are using earphones, separate the microphone and earphones or reduce the volume.
- 2 Slide [REC/LP MODE →] to the right.

 Slide again the switch to select LP2/LP4
- 3 Press [►/II] to start recording.
- Pace the microphone towards the source of the sound.

■To pause recording

Press [►/II]. (The number of tracks increases by one.)

Recording restarts when pressed again.

■To stop recording Press [■/OPR OFF].

(UTOC is recorded.)

- The unit powers itself off automatically in about a minute.
- You can turn off the unit by pressing again [OPR OFF] on the main unit while stopped.

■Track marks

Add track marks manually or have the unit add them at selected intervals. (See next page.)

■For stereo recording

Purchase a stereo microphone, part number RP-VC200 or RP-VC300.

Other recording functions

Refer to the illustrations on pages 26 and 27 of the Japanese text.

Ways of adding track marks

Apart from auto marking where the unit automatically adds the track marks during recording, there are also the manual and auto time marking methods.

Press [MARK MODE] while the unit is in the recording standby mode to select the required marking method.

The mode changes each time the button is pressed.

AUTO (

Track marks are added automatically when the tracks change.

MANUAL

Track marks can be added manually where required.

3MIN

Track marks are inserted at 3 minute intervals.

5MIN

Track marks are inserted at 5 minute intervals.

10MIN---

Track marks are inserted at 10 minute intervals.

Note

"AUTO" cannot be selected when recording with a microphone.

■To add track marks manually

Main unit

Press [MARK MODE] when a track mark is required during recording.

Remote control

Press [T.MARK/EQ] during recording.

Note

Track marks are added manually even if "MANUAL" has not been selected.

Checking the remaining time on the MD

This function allows you to check the time available for recording while in recording standby mode or in progress.

Remote control only

Press and hold [• LIGHT/ DISP] while in recording standby mode or during recording.

The display changes each time this is done to show elapsed recording time and the remaining recording time.

Note

The available time for recording corresponds to the currently selected recording mode; LP2 or LP4.

Adjusting recording sensitivity

Press [EQ/REC SENS] while in recording standby mode.

The mode changes each time the button is pressed.

REC SENS H	(]	
			П

REC SENS L

Manual setting -

REC SENS H is recommended when:

- Analogue recording from portable equipment
- Digital recording from satellite tuners etc.
- Microphone recording of meetings.

REC SENS L is recommended when:

- •Analogue recording from stereo systems
- Normal digital recording.
- Microphone recording of loud live performances etc.

To adjust manually

- 1 Put the unit in recording standby mode.
- 2 Begin playback of the source.
- 3 Press [◄◄] or [▶▶].

Adjust so the meter reaches to between -12 dB and -4 dB.

▶► Recording sensitivity increases.

(The level meter also increases in length.)

I◄ : Recording sensitivity decreases.

(The level meter also decreases in length.)

Note

- •You cannot change the settings during recording.
- The setting is cleared when you finish recording. Adjust again if necessary before starting the next recording.

Playback (Basic play)

Refer to the illustrations on pages 28 to 29 of the Japanese text.

Preparation

- Release HOLD.
- ●Insert a MD
- 1 Connect the remote control and earphones, then insert the remote control's plug into the headphone jack $[\Omega]$ on the unit.
- 2 Main unit

Press [►/II] to start play.

Remote control

Press [▶/■] to start play.

The unit stops automatically when all the tracks on the disc have been played.

- 3 Adjust the volume.
 - +: To increase the volume level
 - -: To decrease the volume level Volume level is 0-25.

■To pause play

Main unit

Press [►/II] during play.

Playback starts when pressed again.

■To stop the disc

Main unit

Press [■/OPR OFF].

Remote control

Press [▶/■].

- •The unit powers itself off automatically in about a minute.
- •You can turn off the unit by pressing again 「■/OPR OFFI on the main unit while

■Playback for long times

• MDLP

You can play tracks recorded with MDLP mode. "LP-2" or "LP-4" is displayed.

Monaural playback

If a disc was recorded monaurally, the unit automatically switches to monaural playback mode.

The unit selects the play mode according to the recording mode: normal stereo. 2 x play stereo (LP2), or 4 x play stereo (LP4). monaural.

■Resume function

The unit stores the point at which play was stopped and if [>/II] on the main unit or [▶/■] on the remote control is pressed again, play begins from that point. This does not work if the unit is opened or if the battery is removed. The unit starts play from the first track in these cases.

To listen through the speakers

Refer to the illustration on page 30 of the Japanese text.

- 1. Insert a rechargeable battery into the unit.
- 2 Install the unit to the multi cradle
- 3. Connect the AC adaptor to the multi cradle.
- 4. Connect the speakers to the multi cradle.

To operate the settings for the speakers use the same process as for stereo earphones.

Adjusting the volume

Can also be performed using the multi cradle [--+-, VOL/CURSOR] buttons.

Note

- ■Make sure you connect the AC adaptor as sound will not be produced by the speakers if you use only batteries.
- •You may listen to the music you are recording via the speakers (excepting when vou are recording using a microphone).

Other playback functions

Refer to the illustrations on pages 31 to 36 of the Japanese text.

Skip

This function skips tracks and play begins from the beginning of the selected track. Remote control

Main unit

Press [| ◀ ◀ . ▶ ▶ |] during play.

Forward: [| Backward: [|

If you keep the button depressed the unit will continue to skip tracks

Search

This function allows you to fast-forward or rewind through tracks.

Main unit

Remote control

Press and hold [| d | . | b |] during play. Forward: [▶▶] Backward: [|◄◄]

Track select

This function allows you to begin listening from a selected track.

Main unit

Remote control

Press [|◄◄. ▶▶|] while stopped to select the track you like.

Forward: [►►] Backward: [◄◄] If you keep the button depressed the unit will continue to skip tracks

Main unit

Press [►/II] to start play.

Remote control Press [▶/■] to start play.

Play starts from the selected track and plays through to the final track.

Intro-scan memory

You can operate this function only using remote control.

Scan the introductions of tracks and program a maximum of 16 tracks in the order you want to hear them.

■Program the tracks

1. While stopped, press [PLAY MODE] until "INTRO" appears.

The unit powers itself off in about 1 minute if you do not perform another operation.

2. Press [▶/■].

- The first 10 seconds of each track are played in order (intro-scan).
- You can skip tracks during intro-scan.
- 3. Press [T.MARK/EQ] while the track number is flashing to program the track. When the introduction of the last track is played, intro-scan starts again from the beginning. Tracks you have programmed are not played again.
- 4. Repeat step 3 to program all the tracks you want.
- Press [►/■] to finish programming. You can start play of the program by pressing [►/■].

■If "END" or "FULL" is displayed

You cannot program any more tracks.

END: you have programmed all tracks on the

FULL: you have programmed the maximum of 16 tracks.

Programming ends 2 seconds after either of these is displayed.

■To make a new program

Clear all tracks

While stopped and "MEMO" is on the display. press and hold [T.MARK/EQ] for about 5 seconds.

"CLEAR" is displayed and all tracks are cleared. "INTRO" appears on the display after this. Start from step 2.

■To cancel intro scan

Press [PLAY MODE] while stopped.

("INTRO" disappears, the time information is shown, and normal play is restored.)

It is not possible to use intro-scan playback or memory playback (refer right) in group mode. (See page 88.)

Using the program play

If "MEMO" is on the display, start from step 2.

- 1. While stopped, press [PLAY MODE] until "MEMO" appears.
- Press [►/■].
 - •The tracks are played in the programmed
 - •During program play, "MEMO" is displayed after the track's title on the remote control's display.

■To stop play

Press [►/■].

■To cancel program play (The program is stored)

Press [PLAY MODE] while stopped or playing. ("MEMO" disappears, the time information is shown, and normal play is restored.)

■The program is cleared in the following cases

- You Clear all tracks
- The battery goes flat
- You open the disc lid
- You open the battery cover
- You activate recording
- •You press [EDIT] and editing operations are carried out.
- You activate Net MD.

Sound quality

Main unit

Press [EQ/ REC SENS] when the unit is stopped or playing.

Remote control

Press [T.MARK/EQ] when the unit is stopped or playing. The mode changes each time the button is

pressed.

XBS-1 (-----Increases the power of the bass sounds.

XBS-2

Increases the XBS-1 effect.

TRAIN

Reduces sounds that may annoy others when you are using the unit in a public place.

NORMAL (Cancel)

■When listening through the speakers

When the AC adaptor is used as the power source it is possible to change settings as follows:

XBS-SP(
the bass sounds.
NORMAL (Cancel)

Note

You cannot change sound quality during introscan or if "MEMO" is displayed while stopped.

Listening in the group mode

Discs that have been given a group setting (the tracks on the disc have been arranged into a number of groups) allow the listener to select a group and enjoy continuous play of all the songs in that group.

First set the groups. (See page 91.)

Remote control only

 Press and hold [PLAY MODE] while stopped to select "GROUP ON" (group mode).

("GRPON" on the remote control's display)

The group mode and disc mode changes each time the button is pressed.

GROUP ON() GROUP OFF (main unit)

GROUP ON() GROUP OFF (main unit)
GRPON() GRPOFF (remote control)
2. Main unit
Remote control

Press and hold [|◄, ▶►|] to select the group you want to listen (group skip). If you continue to press the button the group changes successively.

Main unit

Press [► / II] to start play.

Remote control

Press [►/■] to start play.

Play will continue to the last song of the selected group and stop.

Note

- •The first song of each group will be indicated by the track number "1".
- If "INTRO" or "MEMO" are displayed [refer to intro-scan memory playback (see page 87)] on the remote control while play is stopped, group mode cannot be used.
- For discs not assigned a group setting "NO GROUP" (on the remote control "NO GRP") will be displayed.

■To skip in the group

Press [| ◀ ◀ . ▶ ▶ |] during play.

■To search in the group

Press and hold [| during play.

■To listen from a selected track in the group

- 1 Press [►] while stopped. Forward : [►] Backward : [►]
- 2 Press [►/II] (main unit) or [►/II] (remote control) to start the play.

Play starts from the selected track and plays through to the final track in the group.

Repeat and Random play

Main unit

Press [MODE] when the unit is stopped or playing.

Remote control

Press [PLAY MODE] when the unit is stopped or playing.

The mode changes each time the button is pressed.

All track repeat ()

All tracks on the disc (or on the group while the unit is in the group mode) are repeated.

Random (RANDOM) (main unit) (RND) (remote control)

All tracks on the disc (or on the group while the unit is in the group mode) are played randomly once each then the unit stops automatically.

Remote control only

Intro-scan memory (INTRO or MEMO)

Normal (no indicator is shown) -----

Note

- •"INTRO" and "MEMO" are only displayed while stopped in the disc mode.
- When using all tracks repeat, you may skip, fast forward or rewind from the first song on the disc (or on the group) to the last (and vice versa) even during playback.
- During random play, it is not possible to skip or rewind to a track that has already been played.
- When changing discs or changing group mode (see left), please reset settings.

Other useful functions

Refer to the illustration on pages 37 to 39 of the Japanese text.

■Adjusting the display's contrast When the unit is powered on:

- 1 Put the main unit in hold (See the illustration on the page 16 of the Japanese text.).
- 2 ①Press and hold [►/II] on the main unit and ...

Main unit
Press [VOL - +1.

Remote control

Press [+, -].

By pressing – or + the contrast will change gradually. Setting can be made in the range as follows.

Main unit: 0 (light) to 29 (dark)
Remote control: 0 (light) to 15 (dark)

+ : darker, - : lighter

■To light the display of the remote control

The display lights for about 5 seconds when an operation is done on the remote control. It remains lit for up to 20 seconds while a track or disc title is scrolling on the screen.

Checking the display of the remote control

Press [• LIGHT/ - DISP].

The display lights for 5 seconds.

■The operation tone of the remote control

A tone sounds when a button on the remote control is pressed.

The tone can be turned on and off.

When the unit is powered on:

- 1 Put the main unit in hold (See the illustration on page 16 of the Japanese text.).
- 2 ①Press and hold [►/II] on the main unit and ...

②To turn on

Press and hold [►/■] until "Beep ON" appears.

To turn off

Press and hold [►/■] until "Beep OFF" appears.

Change the display

Remote control only

Press and hold [• LIGHT/ DISP] when the unit is stopped or playing.

Note

- " * " indicates group names.
- •" indicates disc names.
- "NO TITLE" (" j. f. f " on the remote control) appears when a track, group, or disc has no title.

Remote control

Disc mode

The display changes each time this is done to show the track title, the disc title, playing time of all tracks, total numbers of tracks, elapsed playing time and the track number.

Group mode

The display changes each time this is done to show the track title, the group title, overall group playing time, overall number of tracks in group, group track number and elapsed playing time.

Main unit

Disc mode

The display changes each time this is done to show the remaining playing time, remaining recording time, the disc title, playing time of all tracks, total numbers of tracks, elapsed playing time, the track number and the track title.

Note

The remaining recording time shown corresponds to the recording mode (normal, LP2, or LP4) currently selected.

Group mode

The display changes each time this is done to show the remaining playing time, the group title, overall group playing time, overall number of tracks in group, group track number, elapsed playing time and the track title.

Editing MDs

DIVIDE (Dividing a track into two)

This allows you to add track marks, making it easy to divide a classical piece into its separate movements, for example.

Operation

Refer to the illustration on page 41 of the Japanese text.

- 1 Press [EDIT] during play.
- 2 Press [--, +-, VOL/CURSOR] to select "DIVIDE?".
- 3 Press [ENTER, USB ON/OFF] at the point you want to divide the track.

A 4 second segment (8 seconds if the track is monaural or recorded with LP2, 16 seconds if the track is recorded with LP4) of the track is played repeatedly, beginning at the point selected.

■To adjust the point

Press[--, +-, **VOL/CURSOR**] to adjust the point.

Adjustments can be made approximately 8 seconds (16 seconds if the track is monaural or recorded with LP2, 32 seconds if the track is recorded with LP4) either side of the original point. (-128 to +127)

4 Press [ENTER, USB ON/OFF].

The display asks you to confirm your selection.

5 Press [ENTER, USB ON/OFF].

When "UTOC Writing" goes out editing is complete and the unit stops.

■To stop part way through an editing operation

Press [EDIT] before confirming the operation in step 5.

Note

- •If you divide a track with a title, the latter track becomes untitled.
- DIVIDE cannot be used while the unit is stopped.

MOVE (Moving tracks)

Rearrange the order of the tracks.

Operation

Refer to the illustration on page 42 of the Japanese text.

- 1 Press [EDIT] while stopped.
- 2 Press [--, +-, VOL/CURSOR] to select "MOVE?".
- 3 Press [ENTER, USB ON/OFF].

Now the display is in the mode to select track to be moved.

- 4 Press [--, +-, VOL/CURSOR] to select the track to be moved.
- 5 Press [ENTER, USB ON/OFF].

Now the display is in the mode to select the new position.

- 6 Press [← −, + ←, VOL/CURSOR] again to select the new position.
- 7 Press [ENTER, USB ON/OFF].

The display asks you to confirm your selection.

8 Press [ENTER, USB ON/OFF].

When "UTOC Writing" goes out editing is complete and the unit stops.

■To stop part way through an editing operation

Press [EDIT] before confirming the operation in step 8.

ALL ERASE (Erasing tracks)

Erase all the tracks on the MD.

Operation

Refer to the illustration on page 43 of the Japanese text.

- 1 Press [EDIT] while stopped.
- 2 Press [--, +-, VOL/CURSOR] to select "ALL ERASE?".
- 3 Press [ENTER, USB ON/OFF].

The display asks you to confirm your selection

4 Press [ENTER, USB ON/OFF].

When "UTOC Writing" goes out editing is complete and the unit stops. ("BLANK DISC" appears on the display.)

■To stop part way through an editing operation

Press [EDIT] before confirming the operation in step 4.

Note

ALL ERASE cannot be used while the disc is playing or paused.

TRACK ERASE

Erase one track at a time.

Operation

Refer to the illustration on page 44 of the Japanese text.

- 1 Press [EDIT] while stopped.
- 2 Press [--, +-, VOL/CURSOR] to select "TRACK ERASE?".
- 3 Press [ENTER, USB ON/OFF].

Now the display is in the track selection mode.

- 4 Press [← −, + ←, VOL/CURSOR] to select the track to erase.
- 5 Press [ENTER, USB ON/OFF].

The display asks you to confirm your selection.

6 Press [ENTER, USB ON/OFF]. When "UTOC Writing" goes out editing is complete and the unit stops.

■To stop part way through an editing operation

Press [EDIT] before confirming the operation in step 6.

COMBINE (Combining 2 tracks)

Remove a track mark from between two tracks, effectively making them one track.

Operation

Refer to the illustration on page 45 of the Japanese text.

- 1 Press [EDIT] while playing the latter of the two tracks you want to combine (or while paused).
- 2 Press [--, +-, VOL/CURSOR] to select "COMBINE?".
- 3 Press [ENTER, USB ON/OFF].

The display asks you to confirm your selection. In the example, the last eight seconds of track 2 and the first eight seconds of track 3 play repeatedly (16 seconds if the track is monaural or recorded with LP2, 32 seconds if the track is recorded with LP4)

4 Press [ENTER, USB ON/OFF].

When "UTOC Writing" goes out editing is complete and the unit stops.

■To stop part way through an editing operation

Press [EDIT] before confirming the operation in step 4.

Note

- •The combined track takes the title of the former of the two tracks.
- COMBINE does not work while playing track 1.
 You cannot combine tracks recorded using different modes (monaural, normal stereo, LP2. and LP4).

GROUP (Grouping tracks)

You can do the following

Group set

Group together successive tracks and give groups titles

- Group title
- Change group titles
- Group release

Release tracks from a group

Operation

Refer to the illustration on pages 46 to 49 of the Japanese text.

- 1 Press [EDIT] while stopped.
- 2 Press [--, +-, VOL/CURSOR] to select "GROUP?".
- 3 Press [ENTER, USB ON/OFF].

Now the display is in the function selection mode

4 ①Press [← −, + →, VOL/CURSOR] to select the function.

The mode changes each time the button is pressed.



②Press [ENTER, USB ON/OFF] .

Refer to operation you selected.

GROUP SET

After step 4 above

The display is ready for you to select the first track in the group.

- 5 Press [--, +-, VOL/CURSOR] to select the first track.
- 6 Press [ENTER, USB ON/OFF].

The display is ready for you to select the last track in the group.

- 7 Press [--, +-, VOL/CURSOR] to select the last track.
- 8 Press [ENTER, USB ON/OFF].

The number of the new group is displayed. *After 2 seconds*

The text editing mode is entered.

9 Enter the title. (See pages 92 to 93.)

10 Press [ENTER, USB ON/OFF].

When "UTOC Writing" goes out editing is complete and the unit stops.

■To stop part way through an editing operation

Press [EDIT] before confirming the operation in step 10.

Note

- A group can be made from one track.
- Groups are not operated in the order you create them. They are ordered by track numbers.
- Tracks separated by other tracks cannot be grouped.
- You cannot put the same track into two different groups.

GROUP TITLE

After step 4 on the preceding page

The display is ready for you to select the group to title.

- 5 Press [--, +-, VOL/CURSOR] to select the group you want to title.
- 6 Press [ENTER, USB ON/OFF].
 The text editing mode is entered.
- 7 Enter the title. (See right.)
- 8 Press [ENTER, USB ON/OFF].

When "UTOC Writing" goes out editing is complete and the unit stops.

■To stop part way through an editing operation

Press [EDIT] before confirming the operation in step 8.

•GROUP RELEASE

After step 4 in the page before

The display is ready for you to select the group to release.

- 5 Press [--, +-, VOL/CURSOR] to select the group you want to release.
- 6 Press [ENTER, USB ON/OFF].

The display asks you to confirm your selection.

7 Press [ENTER, USB ON/OFF].

When "UTOC Writing" goes out editing is complete and the unit stops.

■To stop part way through an editing operation

Press [EDIT] before confirming the operation in step 7.

Note

- After using editing functions (e.g., DIVIDE, MOVE, and COMBINE) on a disc with groups, the unit rewrites UTOC to maintain consistent group information.
- If you create groups with this unit and then perform editing on a unit that is incompatible with group functions, the group information may be rendered unusable.
- Disc titles will not be displayed correctly if you play an MD with groups on it on equipment that is incompatible.

Titling MDs

Titling discs and tracks

Refer to the illustration on pages 50 to 51 of the Japanese text.

- Discs and tracks recorded with standard stereo recording mode can have titles with up to 100 characters. Tracks recorded with LP2 or LP4 can have titles with up to 97 characters.
- One MD can hold a maximum of 1792 characters. The number of characters an MD can hold reduces if you use LP2 or LP4 to record tracks and if you put tracks into groups.
- 1 Press [EDIT] while stopped.

"TITLE?" appears on the display.

2 Press [ENTER, USB ON/OFF].

"DISC TITLE?" appears on the display.

When titling a disc

Press [ENTER, USB ON/OFF] again.

The text editing mode is entered.

When titling a track

①Press [——, +—, VOL/CURSOR] to select the track you want to title. ②Press [ENTER, USB ON/OFF].

The text editing mode is entered.

- **4 Enter the title.** (See right.)
- 5 Press [ENTER, USB ON/OFF].

When "UTOC Writing" goes out editing is complete.

■After titling a disc

The display automatically shows the track titling display. Follow the steps for titling tracks

■To stop part way through an editing operation

Press [EDIT] before confirming the operation in step 5.

Note

- •If you start entering a title while a track is playing, the track repeats until you finish.
- If you begin title editing with a disc that has titles longer than 100 characters, "TITLE OVER" is displayed and then the text-editing mode is entered. The unit erases the extra characters when you complete editing.
- •"LP:" are automatically added when you use MDLP to extend recording time, so the number of characters you can put in an MD is reduced. When you put tracks into groups, this group information is also recorded and reduces the number of characters an MD can hold.

Entering text

Refer to the illustrations on pages 52 to 53 of the Japanese text.

Preparation: Put the unit in the text editing mode.

1 Press [CHARA] to select the type of characters.

The type changes each time the button is pressed.

ァ) A)a)1 ^-------

2 Press the character/numbered buttons to select.

The characters changes each time you press the button.

3 Press [+ → VOL/CURSOR]

The character moves to the title section and the unit is ready to accept the next character.

■To erase a character

- 1 Press [--, +-, VOL/CURSOR] to move the cursor over the character you want to erase.
- 2 Press [DELETE].

The characters after the erased character move back to take its place.

- ■To insert an extra character or space
- 1 Press [--, +-, VOL/CURSOR] to move the cursor to the position you want to insert the character or space.
- 2 To insert the character

Press character/numbered button. To insert space

Press [SPACE]

■Correcting titles

- 1 Delete the character you want to correct.
- 2 Insert the character.

■Leaving a space during input

Press [+ -, VOL/CURSOR] to move the cursor one space to the right.

■To stop part way through an editing operation

Press [EDIT].

The normal display is restored.

Note

The symbol "/" cannot be inputted twice or more times in succession.

Copying titles from one MD to another (TITLE STATION)

Refer to the illustration on pages 54 of the Japanese text.

The unit temporarily records the titles from an MD so they can then be copied onto another MD

Before proceeding

- You cannot copy titles from prerecorded MDs or blank MDs.
- •You can copy titles only if both MDs have the same number of tracks.
- If the MD you are copying titles to already has titles, they are replaced with the new titles when this procedure is used.
- When you copy the titles recorded with LP2 or LP4 to the tracks recorded with standard stereo mode, these tracks will have "LP." at the beginning of their title.
- Group information is also copied from the disc being copied.
- 1 Insert the MD with the titles.
- 2 Press [EDIT] while stopped.
- 3 Press [← −, + →, VOL/CURSOR] to select "TITLE COPY?".
- 4 Press [ENTER, USB ON/OFF].

After "TITLE MEMORY" is displayed "TAKEOUT DISC" is displayed when the unit has recorded the titles.

5 Eject the MD.

"CHANGE DISC" is displayed when the lid is opened.

6 Insert the other MD.

After "TOC Reading" is displayed, the display asks you to confirm the operation.

7 Press [ENTER, USB ON/OFF].

When "UTOC Writing" goes out editing is complete and the unit stops.

■To stop part way through an editing operation

Press [EDIT] before confirming the operation in step 7.

Using in combination with a computer

Refer to the illustration on pages 55 to 63 the Japanese text.

What is Net MD?

By connecting the unit to a computer via a USB terminal, it is possible to download music data stored in your computer from CDs and internet music sites to the unit's MD.

■What you can do with Net MD

- You can use BeatJam to convert the music data stored in your computer to OpenMG format, send it to MD player and record it onto MD.
- You may record in LP2/LP4 mode also. The title of each track will also be recorded.
- •MDs made using Net MD can be listened to just like MDs made from CD using any MD player. It is also possible to record to other MD players using the analog connections.
- There is a limit to the number of times you may checkout to one piece of music data.
- If you return the data checked out to the computer (check-in), you may check out for a second time using another media to use it.
- You may operate to unit from a computer to change the order of songs or add track titles.

Note

- BeatJam and Net MD USB drivers can only be installed on computers using a Windows OS. They cannot be installed on a Macintosh computer.
- •Net MD will only work properly if the unit is used in combination with a computer with the provided software and drivers installed. We cannot guarantee performance if more than one unit is attached at any one time or if the unit is used combination with other Net MD devices.

Installation

- 1 Preinstalling BeatJam and Net MD USB drivers
 - Turn on the computer and boot up the OS.
 - ②Insert the CD-ROM provided into the computer's CD-ROM drive.
 - The Begin Set Up Screen will be displayed.
 - Oclick on "Set Up BeatJam" in the Begin Set Up Screen.

Follow the on screen instructions and install. All necessary drivers and applications will be installed.

2 Connection

Use the USB cable (provided) and connect the unit to a computer.

- 1. Insert a rechargeable battery into the unit.
- 2. Install the unit to the multi cradle.
- 3. Connect the AC adaptor to the multi cradle.
- 4. Connect the USB cable to the multi cradle and the computer.

Refer also to the instruction booklet that came with the computer.

Note

Make sure you use the USB cable that came with this unit

3 Double Check

Confirm that BeatJam and Net MD USB drivers have been correctly installed.

BeatJam

The BeatJam, BeatJam User Registration and BeatStream icons will be displayed on the computer desktop if they have been correctly installed.

Net MD USB driver

Press [ENTER, USB ON/OFF] on the multi cradle to activate Net MD.

The items contained in the on screen list may vary according to the computer environment you are using.

When using Windows 2000 Professional (See the illustrations on page 59 of the the Japanese text.)

When using Windows XP Home Edition/Professional

(See the illustrations on page 59 of the the Japanese text.)

When using Windows 98/98 Second Edition or Windows Millennium Edition

(See the illustrations on page 60 of the the Japanese text.)

Recording onto MD (Checkout)

Refer to the illustration on pages 61 of the Japanese text.

Preparation

- ①Turn on the computer and boot up the OS.
- ②Connect the unit to the computer using a USB cable .
- ③Place a MD for recording and a rechargeable battery into the unit and install the unit onto the multi cradle. Release the write protection catch on the

MD.

- 1 Press [ENTER, USB ON/OFF] when play is stopped or the power is off.
- 2 Activate BeatJam on the computer and record (checkout) the songs you want to record to MD.

Checking out is finished when the "UTOC Writing" goes out.

3 Press [ENTER, USB ON/OFF].

Net MD will stand down

Note

In cases where the track titles were included in the computer data, the titles will also be transferred to the MD.

Returning data to the computer (Checkin)

Refer to the illustration on page 62 of the Japanese text.

Once you have returned a track you checked out to the source computer, you may check it out and use it again on other media.

Preparation

- ①Turn on the computer and boot up the OS.
- ②Connect the unit to the computer using a USB cable.
- ③Place a MD containing the checked out tracks and a rechargeable battery in the unit and install on the multi cradle.
- 1 Press [ENTER, USB ON/OFF] when play is stopped or the power is off.
- 2 Activate BeatJam on the computer and return (check-in) the songs. Checking in is finished when the "UTOC Writing" goes out.
- 3 Press [ENTER, USB ON/OFF]. Net MD will stand down.

Note

Do not carry out any of the following actions while checking in/out - music data may be lost.

- Press [A, EJECT] and remove the unit from the multi cradle.
- Disconnect the USB cable.
- Remove the rechargeable battery or disconnect the AC adaptor.

■Operating the unit from a computer MD play

MD editing

- edit track titles
- •rearrange the order of tracks (MOVE)
- •remove unwanted tracks (ERASE)

Optional accessories

Refer to the illustration on page 64 of the Japanese text.

Listening and recording through other equipment

Disconnect the earphones from the remote control and connect the stereo equipment with one of the following line cords.

If the amplifier's connection is;

a line connection : RP-CAPM3G15

a mini-phone jack : RP-CAM3G15

- •Turn off the power to all units before making connections.
- •Ensure you connect this unit to the input terminals on your stereo. Connection to the output terminals can damage this unit.
- Set sound quality to NORMAL (canceled). (See page 87.)
- •Set the volume on this unit to between 20 and 23.
- ■Replacement joint phones RP-HJ337, RP-HJ237

■Stereo microphone

RP-VC200, RP-VC300

■Nickel-metal hydride rechargeable battery

HHF-1PSC/1B, HHF-AZ01S/1B

主な仕様

形 式:ミニディスクデジタル

オーディオシステム

録 音 方 式:磁界変調オーバー

ライト方式

読み取り方式:半導体レーザー

(= 780 nm)に

よる非接触光学式

エラー訂正方式:アドバンスト クロス

インターリーブ リード

ソロモンコード(ACIRC)

圧縮/伸長方式: ATRAC/ATRAC3方式

チャンネル数:2チャンネル(ステレオ)

1 チャンネル(モノラル) (モノラルは再生のみ)

サンプリング周波数: 44.1 kHz

サンプリングレート 入力: 32 kHz/44.1kHz

コンバーター /48 kHz

周波数特性: 20 Hz~20 kHz

 $(+ 0 dB \sim - 8 dB)$

ワウ・フラッター:測定限界値以下

入 力 端 子

OPT/LINE IN 端子([OPT/LINE IN]は兼用ジャック)

入力インピーダンス: 22 k

入力レベル: SENS H: 178 mV

SENS L: 500 mV

MIC 端子

入力インピーダンス: 600

入力レベル: SENS H: 0.4 mV

SENS L: 2.5 mV

出力端子

負荷インピーダンス: 22

出力レベル: 3.5 mW + 3.5 mW

スピーカー端子

(マルチクレードル) 自荷インピーダンス: 8

出力レベル: 0.9 W + 0.9 W

スピーカー(2個)

インピーダンス:8

電 源

本 体

充電式電池: DC 1.2 V

(専用充電式電池)

乾 電 池: DC 1.5 V

(単3形アルカリ乾電池×1個)

マルチクレードル

ACアダプター: DC 4.5 V

(付属 AC アダプター

100 V AC,50/60 Hz

10 VA 使用時)

電池持続時間(JEITA)

(➡ 右ページ参照)

充 電 時 間

付属ACアダプター使用:約3時間30分

寸法(W x H x D)

本 体 寸 法: 78.2 x 71.6 x 17.9 mm

最大外形寸法:80.4 x 74.6 x 20.1 mm

(JEITA)

質 量:約124 g

(充電式電池含む)

約97g

(充電式電池含まず)

電池持続時間は、水平に置き連続して録音または再生した場合の時間です。使用条件によって短くなる場合があります。

この仕様は、性能向上のため変

更することがあります。

電源「切」時消費電力

... 1.6 W(AC のとき)

電池持続時間 (JEITA)

録音

使用電池	ステレオ (通常)	LP2 ステレオ (2 倍長時間)	LP4 ステレオ (4 倍長時間)
充電式電池 1)	約 13 時間	約 17 時間	約 21 時間
乾電池 ²⁾	約8時間	約 13 時間	約 16 時間
充電式電池 ¹⁾ + 乾電池 ²⁾	約 35 時間	約 46 時間	約 5 6 時間

再生

使用電池	ステレオ (通常)	LP2 ステレオ (2 倍長時間)	LP4 ステレオ (4 倍長時間)
充電式電池 ¹⁾	約 25 時間	約 3 3 時間	約 4 0 時間
乾電池 ²⁾	約 3 9 時間	約 5 0 時間	約 63 時間
充電式電池 ¹⁾ + 乾電池 ²⁾	約 7 0 時間	約90時間	約 110 時間

- 1)付属充電式電池フル充電時
- 2)パナソニックアルカリ乾電池(LR6)使用時

ドルビーラボラトリーズの米国及び外国特許に基づく許諾製品。

この装置は、情報処理装置等電波障害自主規制協議会(VCCI)の基準に基づくクラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。取扱説明書に従って正しい取り扱いをしてください。

さくい

さくいん

あ	1	曲	シ	ン	ク		録	音		•	•	•	2	2
	1	ン	ス	۲	_	ル	•	•	•	•	•	•	5	7
	1	ン	۲		ス	+	ャ	ン						
		メ	Ŧ	IJ	_	再	生	•	•	3	2	~	3	3
		_												
	オ	_	ル	1	レ	_	ス				•	•	4	3
	音	質		•	•			•	•	•	•	•	3	4
か	グ	ル	_	プ						3	5	,	4	6
		ン												
さ	サ	_	チ										3	1
		電												
		ン												
	ス	+	ッ	プ									3	1
		ピ												
t	タ	1	۲	ル									5	0
	タ	1	۲	ル	ス	テ	_	シ	3	ン	,	•	5	4
	タ	1	4:	₹-	- /	7 T	<u> </u>	۲,		2	6	,	6	6
	チ	ェ	ッ	ク	ア	ウ	۲	•		•	•	•	6	1
	チ	I	ッ	ク	1	ン	•	•	•	•	•	•	6	2
	デ	1	バ	1	ド		•	•		•	•	•	4	1
	電	池	残	量	表	示	•	•		•	•	•	1	5
	۲	ラ	ッ	ク	1	レ	_	ス		•	•	•	4	4
	۲	ラ	ッ	ク	指	定	•	•	•	•	•	•	3	1
	۲	ラ	ッ	ク	マ	_	ク		24	1.	2	6.	6	6

は ホールド ・・・・・16
まマイク録音・・・・・25
マニュアルマークモード・26,66
マルチクレードル ・13, 30, 58
ム - ブ ・・・・・・42
⑤ ランダムプレイ・・・・36
リジュームプレイ ・・・28
リピートプレイ・・・・36
A BeatJam · · · · · · 55
HDES20
MDLP • • • • • • 21, 24
Net MD · · · · · · · 55
SCMS67
TOC · · · · · · · · · 66
USB58
UTOC · · · · · · · · 66

<無料修理規定>

- 1.取扱説明書、本体貼付ラベル等の注意書に従った使用状態で保証期間内に故障した場合には、無料修理をさせていただきます。
 - (イ)無料修理をご依頼になる場合には、商品に取扱説明書から 切り離した本書を添えていただきお買い上げの販売店にお 申しつけください。
 - (ロ)お買い上げの販売店に無料修理をご依頼にならない場合に は、お近くのご相談窓口にご連絡ください。
- 2.ご転居の場合の修理ご依頼先等は、お買い上げの販売店またはお近くのご相談窓口にご相談ください。
- 3.ご贈答品等で本保証書に記入の販売店で無料修理をお受けになれない場合には、お近くのご相談窓口へご連絡ください。
- 4.保証期間内でも次の場合には原則として有料にさせていただきます。
 - (イ)使用上の誤り及び不当な修理や改造による故障及び損傷
 - (ロ)お買い上げ後の取付場所の移設、輸送、落下などによる故 障及び損傷
 - (ハ)火災、地震、水害、落雷、その他天災地変及び公害、塩害、 ガス害(硫化ガスなど) 異常電圧、指定外の使用電源 (電圧、周波数)などによる故障及び損傷
 - (二)車両、船舶等に搭載された場合に生ずる故障及び損傷 (ただし、ポータブルCDプレーヤーなどの車載を目的とした 機器を車両に搭載された場合は無料)
 - (ホ) 一般家庭用以外(例えば業務用など)に使用された場合の 故障及び損傷
 - (へ)本書のご添付がない場合
 - (ト)本書にお買い上げ年月日、お客様名、販売店名の記入のない場合、あるいは字句を書き替えられた場合
 - (チ)持込修理の対象商品を直接修理窓口へ送付した場合の送料 等はお客様の負担となります。また、出張修理等を行った 場合には、出張料はお客様の負担となります。
- 5. 本書は日本国内においてのみ有効です。
- 6. 本書は再発行いたしませんので大切に保管してください。
- 7.お近くのご相談窓口は取扱説明書の保証とアフターサービス欄をご参照ください。

修理メモ

この保証書は、本書に明示した期間、条件のもとにおいて無料修理をお約束するものです。従ってこの保証書によって、お客様の法律上の権利を制限するものではありませんので、保証期間経過後の修理についてご不明の場合は、お買い上げの販売店またはお近くのご相談窓口にお問い合わせください。

保証期間経過後の修理や補修用性能部品の保有期間については取扱説明書の「保証とアフターサービス」をご覧ください。

This warranty is valid only in Japan.